




**Right-Hand Side**


Key	Qty.	Serial No.	Part No.	Description
1	1		AR72036	Alternator, water pump (pkg. of 2)
2	1		Z46764	Countershaft to rotary screen (4435)
	1		Z34786	Countershaft to rotary screen (4435HY)
3	1		Z32190	Crankshaft to center shaft
4	1		Z46365	Cleaning fan
5	1		Z46366	Separator
6	1		Z65924	Cylinder
7	1		Z45026	Tailings elevator
8	1		Z47912	Clean grain elevator

**Straw Spreader, Beater, Feeder House**


Key	Qty.	Serial No.	Part No.	Description
1	1		Z32041	Straw spreader
2	1		Z33790	Beater
3	1		Z38186	Feeder house

**Left-Hand Side**

Key	Qty.	Serial No.	Part No.	Description
1	1		Z44761	Front straw chopper
2	1	(-056349)	Z47763	Rear straw chopper
	1	(056350-)	Z55645	Rear straw chopper
3	2		Z43863	Condenser rotary blade (4435HY)
4	1		Z38704	Condenser rotary blade (4435HY)

**Main Hydraulic Pump, Compressor, Unloading Auger**

Key	Qty.	Serial No.	Part No.	Description
1	1		Z34828	Main hydraulic pump
2	1		Z46759	Compressor
3	1		Z51212	Unloading auger
4	1		Z42756	Compressor (4435HY)
5	1		Z45482	Compressor (4435HY)

**Ground Drive, Hydrostatic Drive**

Key	Qty.	Serial No.	Part No.	Description
1	1		AZ37807	Upper ground drive (pkg. of 2)
2	1		Z34099	Lower ground drive
3	1		Z53290	Hydrostatic drive