

FILTER OVERVIEW WITH SERVICE INTERVALS AND CAPACITIES

R4023 Final Tier 4 (FT4) Self-Propelled Sprayer (4.5 L)

ENGINE

OIL FILTER
[RE504836](#)

Change after the first 500 hours. Replace every 500 hours or annually.

(Click here for [capacity](#))

SUSPENSION

AIR DRYER FILTER
[AKK11031](#)

Replace annually.

CAB

FRESH AIR FILTER
[SJ14010](#) (Activated Carbon Kit)

RECIRCULATION AIR FILTER
[SJ14011](#) (Activated Carbon Kit)

Replace every 250 hours or annually.

ENGINE

PRIMARY FUEL FILTER
[RE551507](#)

SECONDARY FUEL FILTER
[RE551508](#)

Replace every 500 hours.

ENGINE

DIESEL EXHAUST FLUID (DEF) DOSING UNIT FILTER
[RE554498](#)

Replace every 4500 hours.

(Click here for [capacity](#))

ENGINE

PRIMARY AIR FILTER
[AL215053](#)

SECONDARY AIR FILTER
[AL215054](#)

Replace primary filter every 1500 hours and secondary filter every 4500 hours or as required.

HYDRAULIC

OIL FILTER
[AT314164](#)

Replace every 500 hours.

(Click here for [capacity](#))

ENGINE

OPEN CRANKCASE VENTILATION (OCV) FILTER
[RE540710](#)

Replace every 1500 hours or two years.

HYDRAULIC

HYDROSTATIC OIL FILTERS
[AN203010](#) (Qty. 2)

Replace every 500 hours.

(Click here for [capacity](#))

HYDRAULIC

RESERVOIR STRAINERS
[AN207571](#) (Qty. 2)

[AN207572](#)

Replace as required.

(Click here for [capacity](#))



JOHN DEERE

Genuine Parts and Service

CAPACITIES

R4023 Final Tier 4 (FT4) Self-Propelled Sprayer (4.5 L)

CAPACITIES (Approximate):

Fuel Tank:

..... 311 L (82 gal)

Diesel Exhaust Fluid (DEF) Tank: John Deere™ Diesel Exhaust Fluid

..... 17 L (4.5 gal)

Cooling System with Heater: Cool-Gard™ II

..... 28.2 L (7.4 gal)

Crankcase including Filter: Plus-50™ II

..... 17 L (4.5 gal)

Hydraulic System:

Torq-Gard™ or Plus-50™ II 10W30

..... 151 L (40 gal)

Final Drives:

GL-5 85W140

Each Hub..... 1.1 L (1.2 qt)

[Return to Filter Overview](#)

