

Coolant, Oil, and Transmission Fluid Capacities

Index

Combines

Cotton Pickers

Cotton Strippers

Forage harvesters

Skid-steer loaders

Sprayers, self-propelled

Telehandlers

Tractors

Windrowers

Machine	Model	Capacities	Description
Combines			
Combine	3300	28 qt. (26.5 L) 7 qt. (6.6 L) 14 qt. (13.3 L) 17 qt. (16.2 L) 3.5 qt. (3.3 L)	Coolant Crankcase Reservoir System Transmission
Combine	4400	25 qt. (23.6 L) 6 qt. (5.7 L) 14 qt. (13.3 L) 17 qt. (16.2 L) 7 qt. (6.6 L)	Coolant Crankcase Reservoir System Transmission
Combine	4420	28 qt. (26.5 L) 12 qt. (11.5 L) 14 qt. (13.3 L) 17 qt. (16.1 L) 7 qt. (6.6 L)	Coolant Crankcase Reservoir System Transmission
Combine	4425	26.4 qt. (25 L) 12 qt. (11.4 L) 21 qt. (20 L) 26.4 qt. (25 L)	Coolant Crankcase Reservoir System
Combine	4435	7 qt. (6.6 L) 26.4 qt. (25 L) 13 qt. (11.8 L) 21.2 qt (20 L) 26 qt. (24.6 L) 26 qt. (24.6 L) 7 qt. (6.6 L)	Transmission Coolant Crankcase Reservoir System Transmission Transmission
Combine	6600	28 qt. (27 L) 29.5 qt. (28.4 L) 10 qt. (9.5 L)	Coolant Coolant w/heater Crankcase (6303, 6329)

Machine	Model	Capacities	Description
		17 qt. (16 L)	Crankcase (6404)
		30 qt. (28.4 L)	System
		11 qt. (10.5 L)	Transmission
Combine	6602	32 qt. (30 L)	Coolant
		33.5 qt. (32.4 L)	Coolant w/heater
		15 qt. (14.2 L)	Crankcase (6362G)
		15 qt. (14 L)	Crankcase (6404TH, 6466TH) (-001500)
		17 qt. (16.1 L)	Crankcase (6404TH, 6466TH) (001500-)
		14 qt. (13.3 L)	Reservoir
		18 qt. (17 L)	Reservoir
		17.5 qt. (16.6 L)	System
		38 qt. (36.1 L)	System
		11 qt. (10.5 L)	Transmission
Combine	6620	32 qt. (31 L)	Coolant
		33.5 qt. (32.4 L)	Coolant w/heater
		17 qt. (17 L)	Crankcase (-458100)
		21 qt. (20 L)	Crankcase (458101-)
		24 qt. (22.7 L)	Hydraulic
		18 qt. (17 L)	Reservoir
		30 qt. (28.4 L)	System
		11 qt. (10 L)	Transmission
Combine	6622	32 qt. (31 L)	Coolant
		33.5 qt. (32.4 L)	Coolant w/heater
		15 qt. (14 L)	Crankcase (-001500)
		17 qt. (16.1 L)	Crankcase (001501-)
		24 qt. (22.8 L)	Hydraulic
		30 qt. (28.4 L)	System
		11 qt. (10 L)	Transmission
Combine	7700	32 qt. (31 L)	Coolant
		33.5 qt. (32.4 L)	Coolant w/heater
		12 qt. (11 L)	Crankcase (362GH) (-002800)
		15 qt. (14 L)	Crankcase (362GH) (002801-)

Machine	Model	Capacities	Description
		12 qt. (11 L)	Crankcase (6404 TH , 6404DH) (-002800)
		15 qt. (14 L)	Crankcase (6404 TH , 6404DH) (002801-008000)
		17 qt. (16 L)	Crankcase (6404 TH , 6404DH) (008001-)
		18 qt. (17 L)	Reservoir
		30 qt. (28.4 L)	System
		11 qt. (10 L)	Transmission
Combine	7720	32 qt. (31 L)	Coolant
		33.5 qt. (32.4 L)	Coolant w/heater
		17 qt. (16.1 L)	Crankcase (-298392)
		21 qt. (19.9 L)	Crankcase, (298393-)
		30 qt. (28.4 L)	Hydrostatic
		18 qt. (17 L)	Reservoir
		24 qt. (22.7 L)	System
		11 qt. (10 L)	Transmission
Combine	7722	35.5 qt. (33.5 L)	Coolant
		21 qt. (20 L)	Crankcase
		24 qt. (22.7 L)	Hydraulic
		68 qt. (64 L)	Hydrostatic
		11 qt. (10 L)	Hydrostatic reservoir
		11 qt. (10 L)	Transmission
Combine	8820	35.5 qt. (33.5 L)	Coolant
		17 qt. (16.1 L)	Crankcase (-298392)
		21 qt. (19.9 L)	Crankcase (298393-)
		24 qt. (22.7 L)	Hydraulic
		18 qt. (17 L)	Reservoir
		30 qt. (28.4 L)	System
		11 qt. (10 L)	Transmission
		20 qt. (18.9 L)	Transmission (add. w/PRWD)
Combine	6600SH	28 qt. (27 L)	Coolant
		29.5 qt. (28.4 L)	Coolant w/heater
		17 qt. (16.1 L)	Crankcase
		14 qt. (13.3 L)	Reservoir

Machine	Model	Capacities	Description
		18 qt. (17 L)	Reservoir
		30 qt. (28.4 L)	System
		11 qt. (10.5 L)	Transmission
		24.5 qt. (23.2 L)	Transmission
Combine	9400	37.5 qt. (35.5 L)	Coolant
		20 qt. (18.9 L)	Crankcase
		17 qt. (16 L)	Gearcase, main
		36 qt. (34 L)	Hydraulic Reservoir
		10 qt. (9.6 L)	Transmission
Combine	9410	37.5 qt. (35.5 L)	Coolant
		20 qt. (18.9 L)	Crankcase
		17 qt. (16 L)	Gearcase, main
		36 qt. (34 L)	Hydraulic Reservoir
		10 qt. (9.6 L)	Transmission
Combine	9450	38 qt. (36 L)	Coolant
		20 qt. (18.9 L)	Crankcase
		17 qt. (16 L)	Gearcase, main
		36 qt. (34 L)	Hydraulic Reservoir
		10 qt. (9.6 L)	Transmission
Combine	9500SH	37.5 qt. (35.5 L)	Coolant
		26.5 qt. (25 L)	Crankcase
		17 qt. (16 L)	Gearcase, main
		36 qt. (34 L)	Reservoir
		10 qt. (9.6 L)	Transmission
Combine	9500	37.5 qt. (35.5 L)	Coolant
		26.5 qt. (25 L)	Crankcase
		17 qt. (16 L)	Gearcase, main
		36 qt. (34 L)	Reservoir
		10 qt. (9.6 L)	Transmission
Combine	9510SH	37.5 qt. (35.5 L)	Coolant
		26.5 qt. (25 L)	Crankcase

Machine	Model	Capacities	Description
		17 qt. (16 L) 36 qt. (34 L) 10 qt. (9.6 L)	Gearcase, main Reservoir Transmission
Combine	9510	37.5 qt. (35.5 L) 26.5 qt. (25 L) 17 qt. (16 L) 36 qt. (34 L) 10 qt. (9.6 L)	Coolant Crankcase Gearcase, main Reservoir Transmission
Combine	9550SH	42 qt. (40 L) 33.8 qt. (32 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic reservoir
Combine	9550	42 qt. (40 L) 33.8 qt. (32 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic reservoir
Combine	9560SH	42qt. (40L) 34 qt. (32L) 44qt./42L - 52qt/49L 24qt. (23L)	Coolant Crankcase Hydraulic circuit (2WD/4WD) Gearcase circuit
Combine	9560STS	42 qt. (40L) 31 qt. (29.5L) 44qt./42L - 52qt/49L 24qt. (23L)	Coolant Crankcase Hydraulic circuit (2WD/4WD) Gearcase circuit
Combine	9560	42qt. (40L) 34 qt. (32L) 44qt./42L - 52qt/49L 24qt. (23L)	Coolant Crankcase Hydraulic circuit (2WD/4WD) Gearcase circuit
Combine	9570STS	45.5 qt. (43L) 34 qt. (32L) 37qt./35L 10qts (9.6L)	Coolant Engine Crankcase Hydraulic /Hydrostatic reservoir Transmission

Machine	Model	Capacities	Description
Combine	9600	22.5 qt. (21.3L) 8.5 qts (8l)	Engine Gearcase Final Drives
		37.5 qt. (35.5 L) 26.5 qt. (25 L) 17 qt. (16 L) 36 qt. (34 L) 10 qt. (9.6 L)	Coolant Crankcase Gearcase, main Reservoir Transmission
Combine	9610	30 qt. (28.5 L) 40 qt. (38 L) 36 qt. (34 L) 17 qt. (16 L) 10 qt. (9.6 L)	Crankcase Crankcase (high output) Hydraulic reservoir Gearcase, main Transmission
		40 qt. (38 L) 30 qt. (28.5 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic reservoir
Combine	9650STS	48 qt. (45 L)	Coolant
		31 qt. (29.5 L) 36 qt. (34 L) 36 qt. (34 L) 10 qt. (9.6 L)	Crankcase Hydraulic reservoir Hydraulic reservoir Transmission
Combine	9650	42 qt. (40 L) 30 qt. (28.5 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic reservoir
		42 qt. (40L) 31 qt. (29.5)	Coolant Crankcase
Combine	9660STS	48 qt. (45L) 31 qt. (29.5L) 36 qt. (34L) 22.5qt. (21.3L)	Coolant Crankcase Hydraulic Gearcase circuit

Machine	Model	Capacities	Description
Combine	9660	42 qt. (40L) 32 qt. (29.5L) 44qt. (42L) 52qt. (49L) 24qt. (23L)	Coolant Crankcase Hydraulic circuit 2WD Hydraulic circuit 4WD Gearcase circuit
Combine	9670STS	56 qt. (53L) 30.7 qt. (29L) 37qt. (35L) 10qt. (9.6L) 22.5 qt. (21.3L) 8.5 qt. (8L)	Coolant Engine Crankcase Hydraulic /Hydrostatic reservoir Transmission Engine Gearcase Final Drives
Combine	9770STS	56 qt. (53L) 30.7 qt. (29L) 37qt. (35L) 10qt. (9.6L) 22.5 qt. (21.3L) 54 qt. (51L) 8.5 qt. (8L)	Coolant Engine Crankcase Hydraulic /Hydrostatic reservoir Transmission Engine Gearcase Engine Gearcase (Prodrive) Final Drives
Combine	9750STS	48 qt. (45 L) 30 qt. (28.5 L) 36 qt. (34 L) 10 qt. (9.6L)	Coolant Crankcase Hydraulic reservoir Transmission
Combine	9760STS	48 qt. (45L) 31 qt. (29.5L) 36qt. (34L) 10 qt. (9.6L) 22.5 qt. (21.3L)	Coolant Crankcase Hydraulic Transmission Gearcase
Combine	9770STS	56 qt. (53L) 30.7 qt. (29.5L) 37qt. (35L) 10 qt. (9.6L)	Coolant Engine Crankcase Hydraulic /Hydrostatic reservoir Transmission

Machine	Model	Capacities	Description
		22.5 qt. (21.3L) 8.5 qt. (8L)	Engine Gearcase Final Drives
Combine	9860STS	48 qt (45L) 22.5 qt. (21.3L) 71.6 qt. (67.7L) 44.3 qt. (42L) 10 qt. (9.6L)	Hydraulic reservoir Engine Gearcase Coolant Engine Crankcase Transmission
Combine	9870STS	68.7 qt. (65L) 44.3 qt. (42L) 37qt./35L 10qts (9.6L) 22.5 qt. (21.3L) 32 qt. (30.3L)	Coolant Engine Crankcase Hydraulic /Hydrostatic reservoir Transmission Engine Gearcase Engine Gearcase with multi-speed feeder house
Combine	CTS	42 qt. (39.7L) 26.5 qt. (23.25 L) 36 qt. (34 L) 10 qt. (9.6 L)	Coolant Crankcase Gearcase, main Transmission
Combine	CTS II	38 qt. (36 L) 24.5 qt. (23.2 L) 36 qt. (34 L) 17. qt. (16 L) 10 qt. (9.6 L)	Coolant Engine Gearcase, main Power steering Transmission
<i>Cotton Pickers</i>			
Cotton Picker	7760	68 qt. (64.4 L) 44 qt. (41 L) 260 qt. (246 L) 368 qt. (348.3 L) 20 qt. (19 L)	Coolant Crankcase Reservoir System Transmission

Machine	Model	Capacities	Description
Cotton Picker	9900	28 qt. (26.5 L) 10 qt. (9.5 L) 12 qt. (11.4 L) 18.4 qt. (17.4 L) 22 qt. (20.8 L) 29 qt. (27.4 L) 24 qt. (22.7 L)	Coolant Crankcase Reservoir Reservoir System System Transmission (standard)
Cotton Picker	9910	28 qt. (26.5 L) 12 qt. (11.4 L) 12 qt. (11.4 L) 18.4 qt. (17.4 L) 22 qt. (20.8 L) 29 qt. (27.4 L) 21 qt. (19.9 L)	Coolant Crankcase Reservoir Reservoir System System Transmission (standard)
Cotton Picker	9920	32 qt. (30 L) 12 qt. (11.4 L) 21 qt. (19.9 L) 18.4 qt. (17.4 L) 27 qt. (25.6 L) 24 qt. (22.7 L)	Coolant Crankcase Hydraulic Reservoir System Transmission (standard)
Cotton Picker	9930	34 qt. (32 L) 14.8 qt. (14 L) 18.4 qt. (17.4 L) 21 qt. (19.9 L) 27 qt. (25.5 L) 24 qt. (22.7 L)	Coolant Crankcase Reservoir System System Transmission (standard)
Cotton Picker	9935	34 qt. (32.2 L) 20 qt. (18.8 L) 18.4 qt. (17.4 L) 2 qt. (1.9 L) 27 qt. (25.6 L) 84 qt. (79.5 L) 14 qt. (13.6 L)	Coolant Crankcase Reservoir Reservoir System System Transmission

Machine	Model	Capacities	Description
Cotton Picker	9940	44 qt. (42 L) 21 qt. (19.9 L) 18.4 qt. (17.4 L) 28 qt. (26.5 L) 32.5 qt. (30.7 L)	Coolant Crankcase Reservoir System System
Cotton Picker	9950	44 qt. (42 L) 24.3 qt. (23 L) 18.4 qt. (17.4 L) 28 qt. (26.5 L) 33 qt. (31.2 L)	Coolant Crankcase Reservoir System Transmission
Cotton Picker	9960	44 qt. (42 L) 24.3 qt. (23 L) 36 qt. (34 L) 66 qt. (52.5 L) 22 lb. (10 kg)	Coolant Crankcase Reservoir System Transmission
Cotton Picker	9965	44 qt. (42 L) 24.3 qt. (23 L) 36 qt. (34 L) 66 qt. (52.5 L) 22 lb. (10 kg)	Coolant Crankcase Reservoir System Transmission
Cotton Picker	9970	32 qt. (30 L) 33.3 qt. (31.5 L) 36 qt. (34 L) 66 qt. (62.5 L) 8 qt. (7.6 L)	Coolant Crankcase Reservoir System Transmission
Cotton Picker	9976	44 qt. (42 L) 33.8 qt. (32 L) 11.3 qt. (10.7 L)	Coolant Crankcase Hydrostatic
Cotton Picker	9986	44 qt. (42 L) 31 qt. (29 L)	Coolant Crankcase

Machine	Model	Capacities	Description
		72 qt. (66 L) 7 qt. (6.6 L)	Hydraulic Transmission
Cotton Picker	9996	44 qt. (42 L) 31 qt. (29 L) 18.0 Gal. (66 L) 25.5 Gal. (96.5 L) 10 qt. (9.5 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system Transmission
<i>Cotton Strippers</i>			
Cotton Stripper	482	28 qt. (26.5 L) 10 qt. (9.5 L) 27 qt. (25.5 L)	Coolant Crankcase Hydrostatic
Cotton Stripper	484	28 qt. (26.5 L) 12 qt. (11.4 L) 21 qt. (19.8 L) 27 qt. (25.5 L)	Coolant Crankcase Hydraulic Hydrostatic
Cotton Stripper	7440	32 qt. (30.3 L) 12 qt. (11.4 L) 18.4 qt. (17.4 L) 34 qt. (32.2 L) 18.4 qt. (17.4 L) 27 qt. (25.5 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system Hydrostatic reservoir Hydrostatic system
Cotton Stripper	7445	34 qt. (32 L) 12 qt. (11.4 L) 34 qt. (32.2 L) 27 qt. (25.5 L) 18.4 qt. (17.4 L)	Coolant Crankcase Hydraulic system Hydrostatic system Reservoir
Cotton Stripper	7450	34 qt. (32 L) 12 qt. (11.4 L) 18.4 qt. (17.4 L) 34 qt. (32.2 L) 18.4 qt. (17.4 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system Hydrostatic reservoir

Machine	Model	Capacities	Description
		27 qt. (25.6 L)	Hydrostatic system
Cotton Stripper	7455	34 qt. (32 L) 12 qt. (11.4 L) 18.4 qt. (17.4 L) 34 qt. (32.2 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system
Cotton Stripper	7460	35 qt. (33.1 L) 21 qt. (20 L) 86.4 qt. (81.8 L) 124 qt. (117.3 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system
<i>Forage harvesters</i>			
Forage harvester, Self-propelled	5200	44 qt. (41.6 L) 17 qt. (16.1 L) 12 qt. (11.3 L) 15 qt. (19 L) 28 qt. (26.5 L) 44 qt. (41.6 L) 11 qt. (10.4 L)	Coolant Crankcase Hydraulic Hydraulic w/hydraulic outlet Hydrostatic w/o PRWD Hydrostatic w/PRWD Transmission
Forage harvester, Self-propelled	5400	60 qt. (56.8 L) 26 qt. (24.6 L) 12 qt. (11.3 L) 15 qt. (19 L) 28 qt. (26.5 L) 44 qt. (41.6 L) 11 qt. (10.4 L)	Coolant Crankcase Hydraulic Hydraulic w/hydraulic outlet Hydrostatic w/o PRWD Hydrostatic w/PRWD Transmission
Forage harvester, Self-propelled	5440	12 qt. (11.3 L) 15 qt. (19 L) 28 qt. (26.5 L) 44 qt. (41.6 L) 11 qt. (10.4 L) 44 qt. (41.6 L) 17 qt. (16.1 L)	Hydraulic Hydraulic w/hydraulic outlet Hydrostatic w/o PRWD Hydrostatic w/PRWD Transmission Coolant Crankcase

Machine	Model	Capacities	Description
Forage harvester, Self-propelled	5460	60 qt. (56.8 L) 24 qt. (22.7 L) 12 qt. (11.3 L) 15 qt. (19 L) 28 qt. (26.5 L) 44 qt. (41.6 L) 11 qt. (10.4 L)	Coolant Crankcase Hydraulic Hydraulic w/hydraulic outlet Hydrostatic w/o PRWD Hydrostatic w/PRWD Transmission
Forage harvester, Self-propelled	5720	44 qt. (41.6 L) 20 qt. (18.9 L) 12 qt. (11.3 L) 15 qt. (19 L) 28 qt. (26.5 L) 44 qt. (41.6 L) 11 qt. (10.4 L)	Coolant Crankcase Hydraulic Hydraulic w/hydraulic outlet Hydrostatic w/o PRWD Hydrostatic w/PRWD Transmission
Forage harvester, Self-propelled	5730	44 qt. (41.6 L) 20 qt. (18.9 L) 40 qt. (38 L) 44 qt. (41.6 L) 18 qt. (17 L) 44 qt. (41.6 L) 28 qt. (26.5 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system Hydrostatic reservoir Hydrostatic w/PRWD Hydrostatic w/o PRWD
Forage harvester, Self-propelled	5820	60 qt. (56.8 L) 26 qt. (24.6 L) 28 qt. (26.5 L) 44 qt. (41.6 L) 18 qt. (17 L) 11 qt. (10.4 L)	Coolant Crankcase Hydrostatic w/o PRWD Hydrostatic w/PRWD Reservoir Transmission
Forage harvester, Self-propelled	5830	60 qt. (56.8 L) 24 qt. (22.7 L) 44 qt. (41.6 L) 18 qt. (17 L) 11 qt. (10.4 L) 28 qt. (26.5 L)	Coolant Crankcase Hydrostatic w/PRWD Reservoir Transmission Hydrostatic w/o PRWD

Machine	Model	Capacities	Description
Forage harvester, Self-propelled	6610	49.6 qt. (47 L) 25.2 qt. (24 L) 48.8 qt. (46 L) 10 qt. (9.5 L)	Coolant Crankcase Hydraulic (main) Transmission
Forage harvester, Self-propelled	6650	49.6 qt. (47 L) 30.1 qt. (28.5 L) 70.4 qt. (66.5 L) 7.4 qt. (7 L)	Coolant Crankcase Hydraulic (main) Transmission
Forage harvester, Self-propelled	6710	58 qt. (55 L) 37.6 qt. (35.5 L) 10 qt. (9.5 L) 48.4 qt. (46 L) 41.2 qt. (39 L)	Coolant Crankcase Transmission Hydraulic (main) Hydraulic with Rear Wheel Drive
Forage harvester, Self-propelled	6750	63.6 qt. (60 L) 44.4 qt. (42 L) 70.4 qt. (66.5 L) 7.4 qt. (7 L)	Coolant Crankcase Hydraulic (main) Transmission
Forage harvester, Self-propelled	6810	67.6 qt. (64 L) 44.4 qt. (42 L) 48.8 qt. (46 L) 41.2 qt. (39 L) 10 qt. (9.5 L)	Coolant Crankcase Hydraulic (main) Hydraulic with Rear Wheel Drive Transmission
Forage harvester, Self-propelled	6850	63.6 qt. (60 L) 44.4 qt. (42 L) 70.4 qt. (66.5 L) 18 qt. (17 L)	Coolant Crankcase Hydraulic (main) Transmission
Forage harvester, Self-propelled	6910	67.6 qt. (64 L) 44.4 qt. (42 L) 48.8 qt. (46 L) 41.2 qt. (39 L) 10 qt. (9.5 L)	Coolant Crankcase Hydraulic (main) Hydraulic with Rear Wheel Drive Transmission

Machine	Model	Capacities	Description
Forage harvester, Self-propelled	6950	80.4 qt. (80 L) 44 qt. (41.7 L) 70.4 qt. (66.5 L) 10 qt. (9.5 L)	Coolant Crankcase Hydraulic (main) Transmission
Forage harvester, Self-propelled	7200	59 qt. (56L) 30 qt. (28.5L) 95 qt. (90L) 13 qt. (12L)	Coolant Crankcase Hydraulic Power Rear Axle ADD
Forage harvester, Self-propelled	7250	50.8 qt. (48L) 29.5 qt. (28L) 95 qt. (90L) 102.4 qt. (97L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with 3-Speed Hydraulic with ProDrive Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7300	63 qt. (60L) 44 qt. (42L) 95 qt. (90L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7350	63.4 qt. (60L) 63.4 qt. (60L) 95 qt. (90L) 102.4 qt. (97L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with 3-Speed Hydraulic with ProDrive Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7400	74.8 qt. (71L) 44 qt. (42L) 95 qt. (90L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic Power Rear Axle (Narrow) Power Rear Axle (Wide)

Machine	Model	Capacities	Description
Forage harvester, Self-propelled	7450	63.4 qt. (60L) 63.4 qt. (60L) 95 qt. (90L) 102.4 qt. (97L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with 3-Speed Hydraulic with ProDrive Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7500	74.8 qt. (71L) 44 qt. (42L) 95 qt. (90L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7550	63.4 qt. (60L) 63.4 qt. (60L) 95 qt. (90L) 102.4 qt. (97L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with 3-Speed Hydraulic with ProDrive Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7700	74.8 qt. (71L) 44 qt. (42L) 95 qt. (90L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7750	63.4 qt. (60L) 63.4 qt. (60L) 95 qt. (90L) 102.4 qt. (97L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with 3-Speed Hydraulic with ProDrive Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7800	103.2 qt. (98L) 48 qt. (45L) 95 qt. (90L)	Coolant Crankcase Hydraulic

Machine	Model	Capacities	Description
		14.76 qt. (15L) 20.6 qt. (19.5L)	Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7850	103.5 qt. (98L) 47.5 qt. (45L) 95 qt. (90L) 102.4 qt. (97L) 14.76 qt. (15L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with 3-Speed Hydraulic with ProDrive Power Rear Axle (Narrow) Power Rear Axle (Wide)
Forage harvester, Self-propelled	7950	103.5 qt. (98L) 80.2 qt. (76L) 102.4 qt. (97L) 20.6 qt. (19.5L)	Coolant Crankcase Hydraulic with ProDrive Power Rear Axle (Wide)
Skid-steer loaders			
Skid-steer loader	704 qt. (3.7 L)	Crankcase 60 qt. (56.8 L)	Hydraulic
Skid-steer loader	90	4 qt. (3.7 L) 44 qt. (41.6 L)	Crankcase Hydraulic
Skid-steer loader	170	5 qt. (4.7 L) 80 qt. (75.7 L)	Crankcase Hydraulic
Skid-steer loader	240	11.2 qt. (10.6 L) 7.8 qt. (7.4 L) 24 qt. (23 L)	Coolant Crankcase Hydraulic
Skid-steer loader	250	11.2 qt. (10.6 L) 7.8 qt. (7.4 L) 24 qt. (23 L)	Coolant Crankcase Hydraulic
Skid-steer loader	260	11.2 qt. (10.6 L) 7.8 qt. (7.4 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic

Machine	Model	Capacities	Description
Skid-steer loader	270	14.2 qt. (13.4 L) 12.7 qt. (12 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic
Skid-steer loader	280	14.2 qt. (13.4 L) 12.7 qt. (12 L) 36 qt. (34 L)	Coolant Crankcase Hydraulic
Skid-steer loader	317	7.5 qt. (7 l) 9.5qt (9 L) 8.0 gal (30.3L)	Coolant Crankcase Hydraulic
Skid-steer loader	320	7.5 qt. (7 l) 9.5qt (9 L) 8.0 gal (30.3L)	Coolant Crankcase Hydraulic
Skid-steer loader	325	8.5 qt. (8 l) 13 qt (12.3 l) 13.6 gal. (51.4 L)	Coolant Crankcase Hydraulic
Skid-steer loader	328	8.5 qt. (8 l) 13 qt (12.3 l) 13.6 gal. (51.4 L)	Coolant Crankcase Hydraulic
Skid-steer loader	332	13 qt (12.3 L) 13 qt. (12.3 L) 13.6 gal. (51.4 L)	Coolant Crankcase Hydraulic
Skid-steer loader	375	2.6 qt. (2.5 L) 36 qt. (34 L)	Crankcase Hydraulic
Skid-steer loader	570	6.4 qt. (6 L) 6 qt. (5.7 L) 60 qt. (57 L)	Crankcase Cooling Hydraulic
Skid-steer loader	575	6.4 qt. (6 L)	Crankcase

Machine	Model	Capacities	Description
		6 qt. (5.7 L) 60 qt. (57 L)	Cooling Hydraulic
Skid-steer loader	675	6 qt. (5.7 L) 68 qt. (64.3 L)	Crankcase Hydraulic
Skid-steer loader	3375	2.6 qt. (2.5 L) 36 qt. (34 L)	Crankcase Hydraulic
Skid-steer loader	4475	5.6 qt. (5.3 L) 20 qt. (18.8 L)	Crankcase Hydraulic
Skid-steer loader	5575	5.6 qt. (5.3 L) 20 qt. (18.8 L)	Crankcase Hydraulic
Skid-steer loader	6675	8 qt. (7.6 L) 24 qt. (22.7 L)	Crankcase Hydraulic
Skid-steer loader	7775	8 qt. (7.6 L) 24 qt. (22.7 L)	Crankcase Hydraulic
Skid-steer loader	8875	9 qt. (8.5 L) 27 qt. (25.5 L)	Crankcase Hydraulic
Skid-steer loader	675B	8.4 qt. (8 L) 68 qt. (64.3 L)	Crankcase Hydraulic
<i>Sprayers, self-propelled</i>			
Sprayer, self-propelled	4630	31.1 qt. (92.4 L) 56.8 qt. (53.7 L) 160 qt (151 L) 20.1 qt (19 L)	Coolant Hydraulic reservoir Hydraulic system Crankcase
Sprayer, self-propelled	4700	25 qt. (24 L)	Coolant

Machine	Model	Capacities	Description
		21.7 qt. (20.5 L) 68 qt. (64 L)	Crankcase Hydraulic
Sprayer, self-propelled	4710	25 qt. (24 L) 21.7 qt. (20.5 L) 68 qt. (64 L)	Coolant Crankcase Hydraulic
Sprayer, self-propelled	4720	25 qt. (24 L) 27.5 qt. (26 L) 17.0 Gal (64 L)	Coolant Crankcase Hydraulic
Sprayer, self-propelled	4730	31.1 qt. (92.4 L) 68 qt. (64 L) 172 qt (163 L) 27.5 qt (26 L)	Coolant Hydraulic reservoir Hydraulic system Crankcase
Sprayer, self-propelled	4830	31.1 qt. (92.4 L) 68 qt. (64 L) 172 qt (163 L) 27.5 qt (26 L)	Coolant Hydraulic reservoir Hydraulic system Crankcase
Sprayer, self-propelled	4920	36 qt. (34 L) 30.6 qt. (29 L) 80 qt. (76 L) 172 qt. (163 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system
Sprayer, self-propelled	4930	42.3 qt. (40 L) 32.8 qt. (31 L) 80 qt. (76 L) 172 qt. (163 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system
Sprayer, self-propelled	6000	11.5 qt. (11 L) 9 qt. (8.5 L) 12 qt. (11.4 L) 4 qt. (3.8 L)	Coolant Crankcase Hydraulic Transmission
Sprayer, self-propelled	6100	16 qt. (15.1 L) 12 qt. (11.4 L)	Coolant Crankcase

Machine	Model	Capacities	Description
		48 qt. (45.4 L) 48 qt. (45.4 L) 36.5 qt. (34.5 L)	Hydraulic Hydrostatic system Reservoir
Sprayer, self-propelled	6500	18 qt. (17 L) 12 qt. (10.9 L) 36.48 qt. (34.5 L) 48 qt. (45.4 L) 36.5 qt. (34.5 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system Reservoir
Sprayer, self-propelled	6600	16 qt. (15.1 L) 12 qt. (11.4 L) 48 qt. (45.4 L) 36.5 qt. (34.5 L)	Coolant Crankcase Hydraulic system Hydraulic reservoir
Sprayer, self-propelled	6700	20 qt. (19 L) 15.5 qt. (14.7 L) 36.48 qt. (34.5 L) 48 qt. (45.46 L)	Coolant Crankcase Hydraulic reservoir Hydraulic system
<i>Telehandlers</i>			
Telescopic Handler	3200	24 qt. (22.5 L) 12.8 qt. (12 L) 188 qt. (180 L) 20.4 qt. (18.5 L)	Coolant Crankcase Hydraulic Transmission
Telescopic Handler	3220	24 qt. (22.7 L) 13.6 qt (12.9 L) 121.2 qt (114.7 L) 24 qt. (22.7 L)	Coolant Crankcase Hydraulic Transmission
Telescopic Handler	3400	24 qt. (22.5 L) 12.8 qt. (12 L) 188 qt. (180 L) 20.4 qt. (18.5 L)	Coolant Crankcase Hydraulic Transmission

Machine	Model	Capacities	Description
Telescopic Handler	3420	24 qt. (22.7 L) 13.6 qt (12.9 L) 121.2 qt (114.7 L) 24 qt. (22.7 L)	Coolant Crankcase Hydraulic Transmission
Telescopic Handler	3800	33 qt. (31L) 13.6 qt. (13L) 160 qt. (151L)	Coolant Crankcase Hydraulic +Transmission
<i>Tractors</i>			
Tractor	670	4 qt. (3.8 L) 2.7 qt. (2.6 L) 16 qt. (15 L)	Coolant Crankcase Hydraulic
Tractor	755	4 qt. (3.8 L) 2.7 qt. (2.6 L) 4.5 Gal.(17 L)	Coolant Crankcase Hydraulic
Tractor	770	5.1 qt. (4.8 L) 4.2 qt. (4.0 L) 4.0 Gal. (15 L)	Coolant Crankcase Hydraulic
Tractor	790	5 qt. (4.73 L) 4.4 qt. (4.16 L) 16 qt. (15.14 L)	Coolant Crankcase Hydraulic
Tractor	820	11 qt. (10.4 L) 6 qt. (5.7 L) 29.6 qt. (28 L)	Coolant Crankcase Hydraulic
Tractor	830	11 qt. (10 L) 6 qt. (5.7 L) 29.6 qt. (28 L)	Coolant Crankcase Hydraulic
Tractor	855	4.8 qt. (4.5 L)	Coolant

Machine	Model	Capacities	Description
		4.1 qt. (3.9 L) 4.5 Gal. (17 L)	Crankcase Hydraulic
Tractor	870	5.1 qt. (4.8 L) 22 qt. (20.8 L)	Crankcase Hydraulic/transmission
Tractor	900HC	4.7 qt. (4.5 L)	Crankcase
Tractor	940	32 qt. (30.2 L) 14 qt. (12.2 L) 33 qt. (31.2 L) 13 qt. (12.3 L)	Coolant Crankcase Hydraulic Transmission
Tractor	955	4.8 qt.(4.5 L) 4.1 qt. (3.9 L) 4.5 Gal. (17 L)	Coolant Crankcase Hydraulic
Tractor	970	6.1 qt. (5.8 L) 5.6 qt. (5.3 L) 22 qt. (20.8 L)	Coolant Crankcase Hydraulic
Tractor	990	6.13 qt. (5.8 L) 5.6 qt. (5.3 L) 22.19 qt. (21 L)	Coolant Crankcase Hydraulic
Tractor	1010	11 qt. (10.4 L) 5 qt. (4.7 L) 3 qt. (2.1L) 4.3 qt. (4.2 L) 13 qt. (12.2 L) 12 qt. (11.2 L)	Coolant Crankcase Final drive (each) Hydraulic Transmission (540PTO) Transmission (dual PTO)
Tractor	1020	11 qt. (10.4 L) 7 qt. (6.6 L) 40 qt. (37.9 L)	Coolant Crankcase Hydraulic
Tractor	1030	11 qt. (10.4 L)	Coolant

Machine	Model	Capacities	Description
		7.4 qt. (7 L) 38 qt. (36 L) 2.6 qt. (2.5 L)	Crankcase Hydraulic MFWD
Tractor	1040	11.1 qt. (10.5 L) 16.4 qt. (15.5 L) 7.4 qt. (7.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L) 34.8 qt. (33 L) 29.5 qt. (28 L)	Coolant w/o cab Coolant w/cab Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	1070	5.6 qt. (5.3 L) 22 qt. (20.8 L)	Crankcase Hydraulic
Tractor	1120	11 qt. (10.4 L) 6 qt. (5.7 L) 38 qt. (36 L)	Coolant Crankcase Hydraulic
Tractor	1130	11 qt. (10.4 L) 7.4 qt. (7 L) 38 qt. (36 L) 2.6 qt. (2.5 L)	Coolant Crankcase Hydraulic MFWD
Tractor	1140	11.1 qt. (10.5 L) 16.4 qt. (15.5 L) 7.4 qt. (7.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L) 34.8 qt. (33 L) 29.5 qt. (28 L)	Coolant w/o cab Coolant w/cab Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	1250	8.4 qt. (8 L)	Coolant

Machine	Model	Capacities	Description
		11.2 qt. (10.5 L) 33.3 qt. (31.5 L) 18 qt. (17 L)	Crankcase Hydraulic MFWD
Tractor	1350	11.1 qt. (10.5 L) 6.3 qt. (6.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L) 34.8 qt. (33 L) 29.5 qt. (28 L)	Coolant Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	1450	11.1 qt. (10.5 L) 12.7 qt. (12 L) 33.3 qt. (31.5 L) 18 qt. (17 L)	Coolant Crankcase Hydraulic MFWD
Tractor	1520	12 qt. (11.4 L) 6 qt. (5.7 L) 40 qt. (37.9 L)	Coolant Crankcase Hydraulic
Tractor	1530	11 qt. (10.5 L) 6 qt. (5.7 L) 29.6 qt. (28 L)	Coolant Crankcase Hydraulic
Tractor	1550	11.1 qt. (10.5 L) 6.3 qt. (6.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L) 34.8 qt. (33 L) 29.5 qt. (28 L)	Coolant Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	1620	11 qt. (10.4 L) 10.5 qt. (10 L) 38 qt. (36 L)	Coolant Crankcase Hydraulic
Tractor	1630	11 qt. (10.4 L)	Coolant

Machine	Model	Capacities	Description
		7.4 qt. (7 L) 38 qt. (36 L) 2.6 qt. (2.5 L)	Crankcase Hydraulic MFWD
Tractor	1640	13.6 qt. (13 L) 16 qt. (15 L) 9 qt. (8.5 L) 47.6 qt. (45 L) 34.8 qt. (33 L) 5.2 qt. (5 L)	Coolant w/o cab Coolant w/cab Crankcase Hydraulic with Synchronized Hydraulic with collar shift Add for H-D final drives
Tractor	1650	11 qt. (10.5 L) 12.7 qt. (12 L) 33.3 qt. (31.5 L) 18 qt. (17 L)	Coolant Crankcase Hydraulic MFWD
Tractor	1750	11.1 qt. (10.5 L) 6.3 qt. (6.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L) 34.8 qt. (33 L) 29.5 qt. (28 L)	Coolant Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	1830	19.5 qt. (18.4 L) 6 qt. (5.7 L) 40 qt. (37.8 L) 12 qt. (11.4 L) 6 qt. (5.7 L) 40 qt. (37.8 L)	Coolant(Dubuque) Crankcase(Dubuque) Hydraulic/transmission(Dubuque) Coolant(Mannheim) Crankcase(Mannheim) Hydraulic/transmission(Mannheim)
Tractor	1850	11.1 qt. (10.5 L) 6.3 qt. (6.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L)	Coolant Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO

Machine**Model****Capacities****Description**[Back to top](#)

		34.8 qt. (33 L) 29.5 qt. (28 L)	Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	1950	11.1 qt. (10.5 L) 6.3 qt. (6.0 L) 50.2 qt. (47.5 L) 53.3 qt. (50.5 L) 55.4 qt. (52.5 L) 34.8 qt. (33 L) 29.5 qt. (28 L)	Coolant Crankcase Hydraulic w/o FWD Hydraulic w FWD Hydraulic w/ front PTO Hydraulic w/o mid PTO Hydraulic w/ mid PTO
Tractor	2010	12 qt. (11.4 L) 5 qt. (4.7 L) 32 qt. (30.3 L)	Coolant Crankcase Hydraulic/transmission
Tractor	2020	12 qt. (11.4 L) 6 qt. (5.7 L) 40 qt. (38 L)	Coolant Crankcase Hydraulic/transmission
Tractor	2030	19.5 qt. (18.4 L) 6 qt. (5.7 L) 40 qt. (37.8 L) 12 qt. (11.4 L) 6 qt. (5.7 L) 40 qt. (37.8 L)	Coolant(Dubuque) Crankcase(Dubuque) Hydraulic/transmission(Dubuque) Coolant(Mannheim) Crankcase(Mannheim) Hydraulic/transmission(Mannheim)
Tractor	2040	11.4 qt. (10.4 L) 7.2 qt. (7 L) 41.2 qt. (39 L) 58 qt. (55 L) 5.6 qt. (5.3 L) 5.6 qt. (5.3 L) 41.2 qt. (39 L) 58 qt. (55 L) 11.4 qt. (10.4 L) 7.2 qt. (7 L)	Coolant(Dubuque) Crankcase(Dubuque) Hydraulic/transmission (Collar-Shift)(Dubuque) Hydraulic/transmission (Syncro)(Dubuque) MFWD(Dubuque) MFWD(Mannheim) Transmission, Collar-Shift(Mannheim) Transmission, Syncro-Range(Mannheim) Coolant(Mannheim) Crankcase(Mannheim)

Machine	Model	Capacities	Description
Tractor	2120	10.6 qt. (10 L) 7.2 qt. (7 L)	Coolant Crankcase
Tractor	2120CDN	10.6 qt. (10 L) 7.2 qt. (7 L)	Coolant Crankcase
Tractor	2140	19 qt. (18 L) 13.6 qt. (13 L) 9 qt. (8.5 L) 40 qt. (38 L) 57.2 qt. (54 L)	Coolant, w/cab Coolant, w/o cab Crankcase Transmission, Collar-Shift Transmission, Syncro-Range
Tractor	2150	36 qt. (34 L) 11.2 qt. (10.5 L) 7.4 qt. (7.0 L) 5.6 qt. (5.3 L) 54 qt. (51 L)	Collar-Shift Coolant Crankcase MFWD Transmission, Syncro-Range
Tractor	2155	29.6 qt. (28 L) 34.8 qt (33 L) 10.4 qt. (10 L) 6.5 qt. (6.0 L) 4.8 qt. (4.6 L) 53.2 qt. (50.5 L) 50 qt. (47.5 L)	Collar-Shift (w/o reverser) Collar-Shift (w/reverser) Coolant Crankcase MFWD Transmission, Syncro-Range (w/MFWD) Transmission, Syncro-Range (w/o MFWD)
Tractor	2240	11.2 qt. (10.6 L) 7.2 qt. (7 L) 58 qt. (55 L) 41.2 qt. (39 L) 36 qt. (34 L) 5.6 qt. (5.3 L) 11.2 qt. (10.6 L)	Coolant(Dubuque) Crankcase(Dubuque) Hydraulic/transmission (Collar-Shift)(Dubuque) Hydraulic/transmission (Syncro-Range) (w/o reverser)(Dubuque) Hydraulic/transmission (Syncro-Range) (w/reverser)(Dubuque) MFWD(Dubuque) Coolant(Mannheim)

Machine	Model	Capacities	Description
		7.2 qt. (7 L) 5.6 qt. (5.3 L) 58 qt. (55 L) 41.2 qt. (39 L)	Crankcase(Mannheim) MFWD(Mannheim) Transmission, Collar-Shift(Mannheim) Transmission, Syncro-Range (w/o reverser)(Mannheim)
		36 qt. (34 L)	Transmission, Syncro-Range (w/reverser)(Mannheim)
Tractor	2250	7.4 qt. (7.0 L) 58 qt. (55 L)	Crankcase Hydraulic/transmission
Tractor	2255	11.2 qt. (10.5 L) 7.4 qt. (7.0 L) 54 qt. (51 L)	Coolant Crankcase Hydraulic/transmission
Tractor	2305 (2005-)	3.4 qt. (3.2 L)	Coolant
		3.4 qt. (3.2 L) 3.4 gal. (13 L)	Crankcase Hydraulic
Tractor	2320 (2005-)	4.1 qt (3.9L)	Coolant
		3.0 qt (2.8L)	Crankcase
Tractor	2355	16 qt. (15 L) 13.6 qt. (13 L) 10.4 qt. (10 L) 5.6 qt. (5.3 L) 5.2 qt. (5 L) 34.8 qt (33 L) 29.6 qt. (28 L) 55.6 qt. (52.5 L) 53.2 qt. (50.5 L) 50 qt. (47.5 L)	3.5 gal. (13.1L) Hydraulic Coolant, w/cab Coolant, w/o cab Crankcase MFWD Transmission, Collar-Shift (w/HDFD) (add) Transmission, Collar-Shift (w/o reverser) Transmission, Collar-Shift (w/reverser) Transmission, Syncro-Range (w/FPTO) Transmission, Syncro-Range (w/MFWD) Transmission, Synro-Range (w/2WD)
Tractor	2355N	34.8 qt (33 L) 29.6 qt. (28 L) 10.4 qt. (10 L) 6.5 qt. (6.0 L) 3.6 qt. (3.5 L)	Collar-Shift (w/o reverser) Collar-Shift (w/reverser) Coolant Crankcase MFWD housing

Machine	Model	Capacities	Description
		50 qt. (47.5 L) 53.2 qt. (50.5 L)	Transmission, Syncro-Range (w/2WD) Transmission, Syncro-Range (w/2WD)
Tractor	2440	12 qt. (11.4 L) 13.6 qt. (13 L) 6 qt. (5.7 L) 40 qt. (38 L) 40 qt. (38 L)	Coolant, w/o cab Coolant, w/cab Crankcase Hydraulic/transmission Hydraulic/transmission
Tractor	2450	16 qt. (15 L) 13.6 qt. (13 L) 9 qt. (8.5 L) 5.6 qt. (5.3 L) 36 qt. (34 L) 54 qt. (51 L)	Coolant, w/cab Coolant, w/o cab Crankcase MFWD Transmission, Collar-Shift Transmission, Syncro-Range
Tractor	2510	14 qt. (13.2 L) 7 qt. (6.6 L) 44 qt. (41.6 L) 32 qt. (30.3 L)	Coolant Crankcase Transmission, Powershift Transmission, Syncro-Range
Tractor		14 qt. (13.2 L) 7 qt. (6.6 L) 44 qt. (41.6 L) 32 qt. (30 L)	Coolant Crankcase Transmission, Powershift Transmission, Syncro-Range
Tractor	2520 (2005-)	4.1 qt (3.9L) 3.0 qt (2.8L) 3.9 gal. (14.6L)	Coolant Crankcase Hydraulic
Tractor	2550	36 qt. (34 L) 16 qt. (15 L) 13.6 qt. (13 L) 9 qt. (8.5 L) 5.3 qt. (5 L) 54 qt. (51 L)	Collar-Shift (w/reverser) Coolant, w/cab Coolant, w/o cab Crankcase MFWD housing Transmission, Syncro-Range

Machine	Model	Capacities	Description
Tractor	2555	34.8 qt. (33 L) 29.6 qt. (28 L) 16 qt. (15 L) 13.6 qt. (13 L) 10.4 qt. (10 L) 5.6 qt. (5.3 L) 55.6 qt. (52.5 L) 53.2 qt. (50.5 L) 50 qt. (47.5 L)	Collar-Shift (w/o reverser) Collar-Shift (w/reverser) Coolant, w/cab Coolant, w/o cab Crankcase FWD housing Transmission, Syncro-Range (w/FPTO) Transmission, Syncro-Range (w/FWD) Transmission, Synro-Range (w/o FWD)
Tractor	2630	12 qt. (11.4 L) 9 qt. (8.5 L) 40 qt. (37.9 L)	Coolant Crankcase Hydraulic/transmission
Tractor	2640	12 qt. (11.4 L) 13.6 qt. (13 L) 9 qt. (8.6 L) 9 qt. (8.6 L) 40 qt. (38 L) 40 qt. (38 L)	Coolant Coolant Crankcase Crankcase Hydraulic/transmission Hydraulic/transmission
Tractor	2650	13.6 qt. (13 L) 9 qt. (8.6 L) 40 qt. (38 L)	Coolant Crankcase Hydraulic/transmission
Tractor	2720 (2005-)	4.2 qt (4.0L) 3.6 qt (3.4L) 4.6 gal. (17.5L)	Coolant Crankcase Hydraulic
Tractor	2750	16 qt. (15 L) 13.6 qt. (13 L) 9 qt. (8.6 L) 58.8 qt. (56 L) 7.3 qt. (7 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission MFWD housing
Tractor	2755	16 qt. (15 L) 13.6 qt. (13 L)	Coolant, w/cab Coolant, w/o cab

Machine	Model	Capacities	Description
		10.4 qt. (10 L) 5.6 qt. (5.3 L) 18 qt. (17 L) 32.8 qt. (31 L)	Crankcase MFWD housing Transmission, Collar-Shift, Transmission, Syncro-Range
Tractor	2840	20 qt. (19 L) 12 qt. (11.4 L) 51.6 qt. (49 L)	Coolant Crankcase Hydraulic/transmission
Tractor	2850	20 qt. (18.9 L) 18 qt. (17 L) 12 qt. (11.5 L) 63.6 qt. (60 L) 7.9 qt. (7 L)	Coolant Coolant, w/o cab Crankcase Hydraulic/transmission MFWD housing
Tractor	2855N	16 qt. (15 L) 13.6 qt. (13 L) 10.4 qt. (10 L) 50 qt. (47.5 L) 3.5 qt. (3.3 L) 53.2 qt. (50.5 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission (w/o FWD) MFWD housing Transmission, Syncro-Range
Tractor	2940	25.2 qt. (24 L) 20 qt. (19 L) 12 qt. (11.5 L) 63.6 qt. (60 L) 6.9 qt. (6.5 L)	Coolant w/cab Coolant, w/o cab Crankcase Hydraulic/transmission MFWD housing
Tractor	2950	20 qt. (19 L) 18 qt. (17 L) 12 qt. (11.5 L) 63.6 qt. (60 L) 7.9 qt. (7 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission MFWD housing
Tractor	2955	20 qt. (19 L) 18 qt. (17 L)	Coolant, w/cab Coolant, w/o cab

Machine	Model	Capacities	Description
		12 qt. (11.5 L) 53 qt. (50.5 L) 50 qt. (47.5 L) 7.9 qt. (7 L)	Crankcase Hydraulic/transmission (w/MFWD) Hydraulic/transmission (w/o MFWD) MFWD housing
Tractor	3005	5 qt. (4.8 L) 3 qt. (2.8 L) 16 qt. (15 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3010	16 qt. (15.1 L) 8 qt. (7.6 L) 38 qt. (36 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3020	19 qt. (18 L) 8 qt. (7.6 L) 44 qt. (41.6 L) 32 qt. (30.9 L)	Coolant Crankcase Transmission, Powershift (2 filters) Transmission, Syncro-Range
Tractor	3030	20 qt. (19 L) 12 qt. (11.5 L) 51.7 qt. (49 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3032E	4.4 qt. (4.2 L) 4.8 qt. (4.5 L) 22 qt. (21 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3038E	4.4 qt. (4.2 L) 4.8 qt. (4.5 L) 22 qt. (21 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3040	24 qt. (25.4 L) 20 qt. (19 L) 12 qt. (11.5 L) 63.4 qt. (60 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission
Tractor	3050	20 qt. (19 L) 18 qt. (17 L)	Coolant, w/cab Coolant, w/o cab

Machine	Model	Capacities	Description
		12 qt. (11.5 L) 52.8 qt. (50 L) 56 qt. (53 L) 58.1 qt. (55 L)	Crankcase Transmission w/ FWD Transmission w/o FWD Transmission w/ front PTO
Tractor	3055	30.1 qt. (19 L) 12 qt. (11.5 L) 34 qt. (32.5 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3120	5.6 qt. (5.3L) 7.2 qt. (7.0L) 5.1 qt (4.8L) 6.3 gal (23.8L) 6.8 gal (25.7L)	Coolant w/o cab Coolant with cab Crankcase Hydraulic (PowrReverser) Hydraulic (eHydro)
Tractor	3130	20 qt. (19 L) 12 qt. (11.5 L) 51.7 qt. (49 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3140	24 qt. (25.4 L) 20 qt. (19 L) 12 qt. (11.5 L) 63.4 qt. (60 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission
Tractor	3150	20 qt. (19 L) 18 qt. (17 L) 12 qt. (11.5 L) 50 qt. (47 L) 7.4 qt. (7 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission MFWD housing
Tractor	3155	20 qt. (19 L) 18 qt. (17 L) 12 qt. (11.5 L) 54 qt. (50.5 L) 50 qt. (47.5 L) 7.4 qt. (7 L)	Coolant, w/cab Coolant, w/o cab Crankcase Hydraulic/transmission (w/MFWD) Hydraulic/transmission (w/o MFWD) MFWD housing

Machine	Model	Capacities	Description
Tractor	3255	20 qt. (19 L) 12 qt. (11.5 L) 38 qt. (35.5 L) 7.4 qt. (7 L)	Coolant Crankcase Hydraulic/transmission MFWD housing
Tractor	3320	5.6 qt. (5.3L) 7.2 qt. (7.0L) 5.1 qt (4.8L) 6.3 gal (23.8L) 6.8 gal (25.7L)	Coolant w/o cab Coolant with cab Crankcase Hydraulic (PowrReverser) Hydraulic (eHydro)
Tractor	3520	5.6 qt. (5.3L) 7.2 qt. (7.0L) 5.1 qt (4.8L) 6.3 gal (23.8L) 6.8 gal (25.7L)	Coolant w/o cab Coolant with cab Crankcase Hydraulic (PowrReverser) Hydraulic (eHydro)
Tractor	3350	20 qt. (19 L) 18 qt. (17 L) 12 qt. (11.5 L) 52.8 qt. (50 L) 56 qt. (53 L) 58.1 qt. (55 L)	Coolant, w/cab Coolant, w/o cab Crankcase Transmission w/ FWD Transmission w/o FWD Transmission w/ front PTO
Tractor	3640	20 qt. (19 L) 12 qt. (11.5 L) 49.6 qt. (47 L)	Coolant Crankcase Hydraulic/transmission
Tractor	3650	20 qt. (19 L) 18 qt. (17 L) 12 qt. (11.5 L) 52.8 qt. (50 L) 56 qt. (53 L) 58.1 qt. (55 L)	Coolant, w/cab Coolant, w/o cab Crankcase Transmission w/ FWD Transmission w/o FWD Transmission w/ front PTO
Tractor	3720	5.6 qt. (5.3L)	Coolant w/o cab

Machine	Model	Capacities	Description
		7.2 qt. (7.0L) 6.0 qt (5.7L) 6.3 gal (23.8L) 6.8 gal (25.7L)	Coolant with cab Crankcase Hydraulic (PowrReverser) Hydraulic (eHydro)
Tractor	4000	24 qt. (23 L) 12 qt. (11.4 L) 8 qt. (7.6 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant Crankcase (diesel) Crankcase (gas/LP) Hydraulic (Powershift) Hydraulic (Synro-Range)
Tractor	4010	2.5 qt. (2.4 L) 2.1 qt (2.0L) 10.5 qt (10 L)	Coolant Crankcase Hydraulic (Hydro)
Tractor	4010 (1963)	23 qt. (21.8 L) 24 qt. (22.7 L) 9 qt. (8.5 L) 44 qt. (41.6 L)	Coolant (diesel) Coolant (gas, LP) Crankcase Hydraulic/transmission
Tractor	4020	24 qt. (23 L) 8 qt. (7.6 L) 12 qt. (11.4 L) 8 qt. (7.6 L) 56 qt. (53 L) 56 qt. (53 L) 40 qt. (38 L)	Coolant Crankcase Crankcase (diesel) Crankcase (gas, LP) Hydraulic/transmission Transmission, Powershift Transmission, Syncro-Range
Tractor	4030	24 qt. (22.7 L) 22 qt. (20.8 L) 17 qt. (16.1 L) 52 qt. (49.2 L)	Coolant w/cab Coolant, w/o cab Crankcase Hydraulic/transmission
Tractor	4040	24 qt. (22.7 L) 16 qt. (15.1 L) 44 qt. (41.6 L)	Coolant Crankcase Transmission, Powershift

Machine	Model	Capacities	Description
		52 qt. (49.2 L)	Transmission, Syncro-Range and Quad-Range
Tractor	4050	27 qt. (25.6 L) 18 qt. (17 L) 63.5 qt. (60 L) 69 qt. (65 L) 9 qt. (8.5 L) 54 qt. (51 L) 64 qt. (60.6 L)	Coolant Crankcase MFWD MFWD MFWD housing Transmission, Powershift (2WD) Transmission, Quad-Range (2WD)
Tractor	4055	27 qt. (25.6 L) 19 qt. (18 L) 63.5 qt. (60 L) 69 qt. (65 L) 12 qt. (11.4 L) 54 qt. (51 L) 64 qt. (60.6 L)	Coolant Crankcase MFWD MFWD MFWD housing Transmission, Powershift (2WD) Transmission, Quad-Range (2WD)
Tractor	4100	2.5 qt. (2.4 L) 2.8 qt. (2.7 L) 11 qt. (10.5 L) 13.2 qt. (12.5 L)	Coolant Crankcase Hydraulic (gear) (no filter) Hydraulic (HST)
Tractor	4110	2.5 qt. (2.4 L) 2.5 qt. (2.2 L) 23.24 qt. (22.0 L) 23.24 qt. (22.0 L)	Coolant Crankcase Transmission (Gear) Transmission (Hydro)
Tractor	4115	2.5 qt (2.4L) 2.1 qt (2.0L) 15.6 qt. (14.6L)	Coolant Crankcase Hydraulic/transmission
Tractor	4120	6.4 qt. (6.2L) 8.8 qt. (8.4L) 7.9 qt. (7.5L) 9.6 gal. (36.1L) 10.3 (38.9L)	Coolant w/o cab Coolant with cab Crankcase Transmission (eHydro) Transmission (PowerReverser)

Machine	Model	Capacities	Description
Tractor	4200	6.4 qt. (6.06 L) 4 qt. (3.7 L) 25 qt. (23.8 L) 27 qt. (25.7 L)	Coolant Crankcase Transmission (Gear) Transmission (Hydro)
Tractor	4210	5.16 qt. (5.3 L) 4.04 qt. (3.82 L) 27.2 qt. (25.74 L) 25.2 qt. (23.85 L)	Coolant Crankcase Transmission (eHydro) Transmission (SST)
Tractor	4230	26 qt. (24.6 L) 24 qt. (22.7 L) 17 qt. (16.1 L) 12 qt. (11.4 L) 40 qt (38 L) 58 qt. (55 L) 44 qt. (42 L) 62 qt. (58.7 L)	Coolant w/cab Coolant w/o cab Crankcase (diesel) Crankcase (gas) Transmission, Powershift (2WD) Transmission, Powershift (PFWD) Transmission, Syncro-Range, Quad-Range (2WD) Transmission, Syncro-Range, Quad-Range (PFWD)
Tractor	4240	30 qt. (28 L) 17 qt. (16 L) 44 qt. (41.6 L) 52 qt. (49.2 L)	Coolant Crankcase Transmission, Powershift Transmission, Syncro-Range and Quad-Range
Tractor	4250	27 qt. (25.6 L) 18 qt. (17 L) 9 qt. (8.5 L) 44 qt. (41.6 L) 63.5 qt. (60 L) 52 qt. (49.2 L) 63 qt. (65 L)	Coolant Crankcase MFWD housing Transmission, Powershift (2WD) Transmission, Powershift (MFWD) Transmission, Quad-Range (2WD) Transmission, Quad-Range (MFWD)
Tractor	4255	27 qt. (25.6 L)	Coolant

Machine	Model	Capacities	Description
		19 qt. (18 L) 12 qt. (11.4 L) 63.5 qt. (60 L) 54 qt. (51.1 L) 64 qt. (60.5 L) 69 qt. (65 L)	Crankcase MFWD housing Transmission, Powershift (MFWD) Transmission, Powershift (2WD) Transmission, Quad-Range (2WD) Transmission, Quad-Range (MFWD)
Tractor	4300	1.7 qt. (1.6 L) 4.5 qt. (4.1 L) 25 qt. (23.8 L)	Coolant Crankcase Transmission (Gear) 27 qt. (25.7 L) Transmission (Hydro)
Tractor	4310	6 qt. (5.68 L) 4.04 qt. (3.82 L) 27.2 qt. (25.74 L) 25.2 qt. (23.85 L) 25.2 qt. (23.85 L)	Coolant Crankcase Transmission (eHydro) Transmission (ePRT) Transmission (SST)
Tractor	4320	6.4 qt (6.2L) 8.0 qt. (7.5L) 9.6 gal. (36.1L) 10.3 (38.9L)	Coolant Crankcase Transmission (eHydro) Transmission (PowerReverser)
Tractor	4320 (1972)	28 qt. (26.5 L) 16 qt. (15.1 L) 56 qt. (53 L) 74 qt. (70 L)	Coolant Crankcase Hydraulic/transmission (2WD) Hydraulic/transmission (PFWD)
Tractor	4400	6.4 qt. (1.6 L) 4.5 qt. (4.1 L) 25 qt. (28.8 L) 27 qt. (25.7 L)	Coolant Crankcase Transmission (Gear) Transmission (Hydro)
Tractor	4410	6 qt. (5.68 L) 4.56 qt. (4.31 L)	Coolant Crankcase

Machine	Model	Capacities	Description
		27.2 qt. (25.74 L) 25.2 qt. (23.85 L)	Transmission (eHydro) Transmission (ePRT)
Tractor	4430	32 qt. (29.9 L) 30 qt. (28 L) 16 qt. (15.1 L) 44 qt. (41.6 L) 52 qt. (49 L) 44 qt. (41.6 L)	Coolant w/cab Coolant w/o cab Crankcase Transmission, Powershift Transmission, QRT, SRT (-033109) Transmission, QRT, SRT (033110-)
Tractor	4440	36 qt. (34 L) 16 qt. (15.1 L) 44 qt. (41.6 L) 52 qt. (49.2 L)	Coolant Crankcase Transmission, Powershift Transmission, Quad-Range
Tractor	4450	27 qt. (25.6 L) 18 qt. (17 L) 9 qt. (8.5 L) 54 qt. (51 L) 63.6 qt. (60 L) 64 qt. (60.5 L) 69 qt. (65 L)	Coolant Crankcase MFWD housing Transmission, Powershift (2WD) Transmission, Powershift (MFWD) Transmission, Quad-Range (2WD) Transmission, Quad-Range (MFWD)
Tractor	4455	27 qt. (25.6 L) 19 qt. (18 L) 63.6 qt. (60 L) 12 qt. (11.4 L) 54 qt. (51 L) 64 qt. (60.5 L) 69 qt. (65.1 L)	Coolant Crankcase MFWD MFWD housing Transmission, Powershift (2WD) Transmission, Quad-Range (2WD) Transmission, Quad-Range (MFWD)
Tractor	4500	7.4 qt. (6.8 L) 5.2 qt. (4.9 L) 27 qt. (25.7 L)	Coolant Crankcase Hydraulic
Tractor	4510	6.4 qt. (6.06 L) 5.08 qt. (4.81 L)	Coolant Crankcase

Machine	Model	Capacities	Description
		39.08 qt. (36.98 L) 39.08 qt. (36.98 L)	Transmission (PRT) Transmission (SST)
Tractor	4520	6.4 qt (6.2L) 8.0 qt. (7.5L) 9.6 gal. (36.1L) 10.3 (38.9L)	Coolant Crankcase Transmission (eHydro) Transmission (PowerReverser)
Tractor	4520 (1970)	28 qt. (26.5 L) 16 qt. (15.1 L) 64 qt. (60.5 L) 82 qt. (77.5 L) 72 qt. (68.1 L) 90 qt. (85.21 L)	Coolant Crankcase Transmission, Powershift (w/o PFWD) Transmission, Powershift (w/PFWD) Transmission, Syncro-Range (w/o PFWD) Transmission, Syncro-Range (w/PFWD)
Tractor	4555	32 qt. (30.3 L) 22 qt. (20.8 L) 12 qt. (11.4 L) 80 qt. (75 L) 74 qt. (70 L) 107 qt. (102 L)	Coolant Crankcase MFWD housing Transmission, Powershift (MFWD) Transmission, Powershift (w/o MFWD) Transmission, Quad-Range
Tractor	4560	32 qt. (30.3 L) 22 qt. (20.8 L) 12 qt. (11.4 L) 80 qt. (75 L) 74 qt. (70 L) 107 qt. (101.8 L)	Coolant Crankcase MFWD housing Transmission, Powershift (MFWD) Transmission, Powershift (w/o MFWD) Transmission, Quad-Range
Tractor	4600	7.6 qt. (7.2 L) 5.2 qt. (4.9 L) 38.8 qt. (37 L) 36.8 qt. (35 L)	Coolant Crankcase Transmission (Gear) Transmission (Hydro)
Tractor	4610	6.8 qt. (6.43 L)	Coolant

Machine	Model	Capacities	Description
		5.08 qt. (4.81 L)	Crankcase
		37 qt. (35.01 L)	Transmission (eHydro)
		39.08 qt. (36.98 L)	Transmission (PRT)
		39.08 qt. (36.98 L)	Transmission (SST)
Tractor	4620	28 qt. (26.5 L)	Coolant
		17 qt. (16 L)	Crankcase
		64 qt. (60.6 L)	Transmission, Powershift
		72 qt. (68.1 L)	Transmission, Synro-Range
Tractor	4630	38 qt. (35.9 L)	Coolant w/cab
		36 qt. (34 L)	Coolant w/o cab
		17 qt. (16 L)	Crankcase
		84 qt. (80 L)	Transmission (QRT) (w/o PFWD) (-017284)
		104 qt. (99 L)	Transmission (QRT) (w/PFWD) (-107284)
		80 qt. (76 L)	Transmission (SRT) (w/o PFWD) (-017284)
		98 qt. (93 L)	Transmission (SRT) (w/PFWD) (-017284)
		84 qt. (80 L)	Transmission (w/o PFWD) (017285-)
		104 qt. (99 L)	Transmission (w/PFWD) (017285-)
		64 qt. (60.6 L)	Transmission, Powershift (w/o PFWD) (-015516)
		48 qt. (46 L)	Transmission, Powershift (w/o PFWD) (015517-)
		82 qt. (77.6 L)	Transmission, Powershift (w/PFWD) (-015516)
		68 qt. (64 L)	Transmission, Powershift (w/PFWD) (015517-)
Tractor	4640	38 qt. (36 L)	Coolant
		20 qt. (19 L)	Crankcase
		66 qt. (62.5 L)	Hydraulic (Powershift)
		82 qt. (77.6 L)	Hydraulic (Powershift) w/ MFWD
		106 qt. (100.3 L)	Hydraulic (Quad-Range) w/ MFWD
		90 qt. (85.2 L)	Hydraulic (Quad-Range)
Tractor	4650	32 qt. (30.3 L)	Coolant

Machine	Model	Capacities	Description
		21 qt. (19.9 L) 9 qt. (8.5 L) 80 qt. (75.7 L) 74.4 qt. (70.5 L) 107 qt. (101.8 L)	Crankcase Hydraulic (MFWD housing) Hydraulic (w/MFWD) Hydraulic (w/o MFWD) Transmission (QRT)
Tractor	4700	7.6 qt. (7.2 L) 5.0 qt. (4.9L) 38.8 qt. (37 L) 36.8 qt. (35 L)	Coolant Crankcase Transmission (Gear) Transmission (Hydro)
Tractor	4710	6.8 qt. (6.43 L) 5.08 qt. (4.81 L) 37 qt. (35.01 L) 39.08 qt. (36.98 L)	Coolant Crankcase Transmission (eHydro) Transmission (PRT)
Tractor	4720	6.4 qt (6.2L) 8.0 qt. (7.5L) 9.6 gal. (36.1L)	Coolant Crankcase Transmission (eHydro)
Tractor	4755	32 qt. (30.3 L) 22 qt. (20.8 L) 80 qt. (75 L) 74.4 qt. (70.5 L) 12 qt. (11.4 L) 107 qt. (101.8 L)	Coolant Crankcase Hydraulic/transmission (w/MFWD) Hydraulic/transmission (w/o MFWD) MFWD housing Transmission (QRT)
Tractor	4760	32 qt. (30.3 L) 22 qt. (20.8 L) 80 qt. (75 L) 74.4 qt. (70.5 L) 12 qt. (11.4 L) 107 qt. (101.8 L)	Coolant Crankcase Hydraulic/transmission (w/MFWD) Hydraulic/transmission (w/o MFWD) MFWD housing Transmission (QRT)
Tractor	4840	40 qt. (38 L) 21 qt. (20 L) 66 qt. (62.5 L)	Coolant Crankcase Hydraulic/transmission

Machine	Model	Capacities	Description
Tractor	4850	32 qt. (30.3 L) 21 qt. (19.9 L) 9 qt. (8.5 L) 74.4 qt. (70.5 L) 80 qt. (75.7 L)	Coolant Crankcase Hydraulic (MFWD housing) Hydraulic/transmission (2WD) Hydraulic/transmission (MFWD)
Tractor	4955	32 qt. (30.3 L) 22 qt. (20.8 L) 107 qt. (101.8 L) 74.4 qt. (70.5 L) 80 qt. (75.7 L) 12 qt. (11.4 L)	Coolant Crankcase Hydraulic/transmission Hydraulic/transmission (2WD) Hydraulic/transmission (MFWD) MFWD housing
Tractor	4960	32 qt. (30.3 L) 22 qt. (20.8 L) 74.4 qt. (70.5 L) 80 qt. (75.7 L) 12 qt. (11.4 L)	Coolant Crankcase Hydraulic/transmission (2WD) Hydraulic/transmission (MFWD) MFWD housing
Tractor	5010	35 qt. (33.1 L) 33 qt. (31.2 L) 21 qt. (19.9 L) 64 qt. (60.5 L)	Coolant w/cab Coolant w/o cab Crankcase Hydraulic/transmission
Tractor	5020	35 qt. (33.1 L) 33 qt. (31.2 L) 20 qt. (18.9 L) 64 qt. (60.5 L)	Coolant w/cab Coolant w/o cab Crankcase Hydraulic/transmission
Tractor	5045D	10 qt. (9.5L) 9 qt. (8.5L) 40 qt. (38L)	Coolant Crankcase Hydraulic
Tractor	5045E	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L) 41.2 qt. (39 L)	Coolant Crankcase Transmission 2WD Transmission MFWD

Machine	Model	Capacities	Description	Back to top
Tractor	5055D	10 qt. (9.5L) 9 qt. (8.5L) 40 qt. (38L)	Coolant Crankcase Hydraulic	
Tractor	5055E	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L) 41.2 qt. (39 L)	Coolant Crankcase Transmission 2WD Transmission MFWD	
Tractor	5065M	15.8 qt. (15 L) 13.8 qt. (13 L) 10.4 qt. (10 L) 56 qt. (53 L)	Coolant w/ cab Coolant w/o cab Crankcase Transmission	
Tractor	5065E	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L) 41.2 qt. (39 L)	Coolant Crankcase Transmission 2WD Transmission MFWD	
Tractor	5075M	15.8 qt. (15 L) 13.8 qt. (13 L) 10.4 qt. (10 L) 56 qt. (53 L)	Coolant w/ cab Coolant w/o cab Crankcase Transmission	
Tractor	5075E	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L) 41.2 qt. (39 L)	Coolant Crankcase Transmission 2WD Transmission MFWD	
Tractor	5083EL	12 qt. (11.4 L) 9 qt. (8.5 L) 46 qt. (43.5 L)	Coolant Crankcase Transmission	
Tractor	5085M	16.4 qt. (15.5 L) 14.3 qt. (13.5 L)	Coolant w/ cab Coolant w/o cab	

Machine	Model	Capacities	Description
		13.8 qt. (13 L) 56 qt. (53 L)	Crankcase Transmission
Tractor	5083EN	12 qt. (11.4 L) 9 qt. (8.5 L) 46 qt. (43.5 L) 48 qt. (45.4 L)	Coolant Crankcase Transmission 12/12 Transmission 24/24
Tractor	5093EN	12 qt. (11.4 L) 9 qt. (8.5 L) 46 qt. (43.5 L) 48 qt. (45.4 L)	Coolant Crankcase Transmission 12/12 Transmission 24/24
Tractor	5093EL	12 qt. (11.4 L) 9 qt. (8.5 L) 46 qt. (43.5 L)	Coolant Crankcase Transmission
Tractor	5095M	16.4 qt. (15.5 L) 14.3 qt. (13.5 L) 13.8 qt. (13 L) 56 qt. (53 L)	Coolant w/ cab Coolant w/o cab Crankcase Transmission
Tractor	5095MH	16.4 qt. (15.5 L) 14.3 qt. (13.5 L) 13.8 qt. (13 L) 56 qt. (53 L)	Coolant w/ cab Coolant w/o cab Crankcase Transmission
Tractor	5101EN	12 qt. (11.4 L) 9 qt. (8.5 L) 46 qt. (43.5 L) 48 qt. (45.4 L)	Coolant Crankcase Transmission 12/12 Transmission 24/24
Tractor	5101EL	12 qt. (11.4 L) 9 qt. (8.5 L) 46 qt. (43.5 L)	Coolant Crankcase Transmission

Machine	Model	Capacities	Description
Tractor	5103	10 qt. (9.5L) 9 qt. (8.5L) 40 qt. (38L) 44 qt. (39L)	Coolant Crankcase Hydraulic with 2WD Hydraulic with 4WD
Tractor	5105	10 qt. (9.5 L) 7.9 qt. (7.5 L) 34 qt. (32 L)	Coolant Crankcase Hydraulic
Tractor	5105M	16.4 qt. (15.5 L) 14.3 qt. (13.5 L) 13.8 qt. (13 L) 56 qt. (53 L)	Coolant w/ cab Coolant w/o cab Crankcase Transmission
Tractor	5105ML	16.4 qt. (15.5 L) 14.3 qt. (13.5 L) 13.8 qt. (13 L) 56 qt. (53 L)	Coolant w/ cab Coolant w/o cab Crankcase Transmission
Tractor	5200	10 qt. (9.5 L) 7 qt. (6.6 L) 40 qt. (38 L) 5.2 qt. (5 L)	Coolant Crankcase Hydraulic/transmission MFWD housing
Tractor	5203	10 qt (9.5L) 9 qt. (8.5L) 40 qt. (38L) 44 qt. (39L)	Coolant Crankcase Hydraulic with 2WD Hydraulic with 4WD
Tractor	5205	10 qt. (9.5 L) 7.9 qt. (7.5 L) 34 qt. (32 L)	Coolant Crankcase Hydraulic
Tractor	5210	10 qt. (9.5 L) 9 qt. (8.5 L) 5.2 qt. (5 L) 44 qt. (42.5 L)	Coolant Crankcase MFWD housing Transmission (left-hand reverser),

Machine	Model	Capacities	Description
		40 qt. (38 L)	Transmission, Collar-Shift and Sync+F4541Shuttle),
Tractor	5220	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L) 46 qt. (43.5 L) 40 qt. (37.8 L)	Coolant Crankcase Transmission (CollarShift) (CS) Transmission (Power Reverser) (PR) Transmission (SyncShuttle) (SST)
Tractor	5225	10 qt. (9.5 L) 11 qt/ (10 L) 10.3 Gal (39 L) 11.5 Gal. (43.5 L) 12.0 Gal (45.4 L)	Coolant Crankcase Transmission & Hydraulic (9/3 SyncShuttle) Transmission & Hydraulic (12/12 PowrReverser) Transmission & Hydraulic (24/24 PowrReverser)
Tractor	5300	10 qt. (9.5 L) 7 qt. (6.6 L) 40 qt. (38 L) 5.2 qt. (5 L)	Coolant Crankcase Hydraulic/transmission MFWD housing
Tractor	5303	10 qt. (9.5L) 9 qt. (8.5L) 40 qt. (38L) 44 qt. (39L)	Coolant Crankcase Hydraulic with 2WD Hydraulic with 4WD
Tractor	5310	10 qt. (9.5 L) 9 qt. (8.5 L) 44 qt. (42.5 L) 5.2 qt. (5 L) 40 qt. (38 L)	Coolant Crankcase Hydraulic reverser MFWD housing Transmission, Collar-Shift and T.S. Sync
Tractor	5320	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L) 46 qt. (43.5 L)	Coolant Crankcase Transmission (CollarShift) (CS) Transmission (Power Reverser) (PR)

Machine	Model	Capacities	Description
		40 qt. (38 L)	Transmission (SyncShuttle) (SST)
Tractor	5325	10 qt. (9.5 L) 11 qt/ (10 L) 10.3 Gal (39 L) 11.5 Gal. (43.5 L)	Coolant Crankcase Transmission & Hydraulic (9/3 SyncShuttle) Transmission & Hydraulic (12/12 PowrReverser)
		12.0 Gal (45.4 L)	Transmission & Hydraulic (24/24 PowrReverser)
Tractor	5403	10 qt. (9.5L) 9 qt. (8.5L) 40 qt. (38L) 44 qt. (39L)	Coolant Crankcase Hydraulic with 2WD Hydraulic with 4WD
Tractor	5400	10 qt. (9.5 L) 9 qt. (8.5 L) 40 qt. (38 L)	Coolant Crankcase Hydraulic/transmission
Tractor	5410	40 qt. (37.8 L) 11.4 qt. (10.8 L) 9 qt. (8.5 L) 5.2 qt. (5 L) 46 qt. (43.5 L)	Collar-Shift and S. Shuttle Coolant Crankcase MFWD housing Power Reverser
Tractor	5420	11.4 qt. (10.8 L) 9 qt. (8.5 L) 40 qt. (38 L) 46 qt. (43.5 L) 40 qt. (38 L)	Coolant Crankcase Transmission (CollarShift) (CS) Transmission (Power Reverser) (PR) Transmission (SyncShuttle) (SST)
Tractor	5425	12.0 qt. (11.4 L) 9.0 qt. (8.5 L) 10.3 Gal. (39 L) 11.5 Gal. (43.5 L)	Coolant Crankcase Transmission & Hydraulic (9/3 SyncShuttle) Transmission & Hydraulic (12/12 PowrReverser)
		12.0 Gal (45.4 L)	Transmission & Hydraulic (24/24 PowrReverser)

Machine	Model	Capacities	Description
Tractor	5500	9 qt. (8.5 L) 46 qt. (43.5 L) 40 qt. (37.8 L)	Crankcase Hydraulic reverser Hydraulic/transmission (Collar-Shift and T. S. Sync)
Tractor	5510	40 qt. (37.8 L) 11.4 qt. (10.8 L) 9 qt. (8.5 L) 5.2 qt. (5 L) 44 qt. (42.5 L)	Collar-Shift and T. S. Sync Coolant Crankcase MFWD housing Power Reverser
Tractor	5520	11.4 qt. (10.8 L) 9 qt. (8.5 L) 40 qt. (38 L) 46 qt. (43.5 L) 40 qt. (38 L)	Coolant Crankcase Transmission (CollarShift) (CS) Transmission (Power Reverser) (PR) Transmission (SyncShuttle) (SST)
Tractor	5520HiCrop	11.4 qt. (10.8 L) 9 qt. (8.5 L) 17.0 gal. (64.3 L) 19.0 Gal. (71.9 L) 17.0 gal. (64.3 L)	Coolant Crankcase Transmission (CollarShift) (CS) Transmission (Power Reverser) (PR) Transmission (SyncShuttle) (SST)
Tractor	5525	12.0 qt. (11.4 L) 9.0 qt. (8.5 L) 10.3 Gal. (39 L) 11.5 Gal. (43.5 L) 12.0 Gal (45.4 L)	Coolant Crankcase Transmission & Hydraulic (9/3 SyncShuttle) Transmission & Hydraulic (12/12 PowrReverser) Transmission & Hydraulic (24/24 PowrReverser)
Tractor	5625	12.0 qt. (11.4 L) 9.0 qt. (8.5 L) 10.3 Gal. (39 L) 11.5 Gal. (43.5 L)	Coolant Crankcase Transmission & Hydraulic (9/3 SyncShuttle) Transmission & Hydraulic (12/12

Machine**Model****Capacities****Description**[Back to top](#)

PowrReverser)

Tractor	6030	40 qt. (37.9 L) 33 qt. (31.2 L) 2 qt. (1.8 L) 26 qt. (24.6 L) 20 qt. (18.8 L) 64 qt. (60.5 L)	Coolant (6531A) Coolant (6531D) Coolant (add. w/cab) Crankcase (6531A) Crankcase (6531D) Hydraulic/transmission
Tractor	6100D	17.4 qt. (16.5 L) 13 qt. (12 L) 61.2 qt. (58 L)	Coolant Crankcase Hydraulic/transmission
Tractor	6110	14.3 qt. (13.5 L) 11.6 qt. (11 L) 12.7 qt. (12 L) 51.6 qt. (49 L) 54.8 qt. (52 L) 1.2 qt. (1 L) 3.2 qt. (3 L) 3.2 qt. (3 L)	Coolant w/cab Coolant w/o cab Crankcase Transmission (PowerQuad) Transmission (SyncroPlus) Extra for Creeper Extra for FWD Extra for TLS
Tractor	6115D	17.4 qt. (16.5 L) 13 qt. (12 L) 61.2 qt. (58 L)	Coolant Crankcase Hydraulic/transmission
Tractor	6120	14.3 qt. (13.5 L) 11.6 qt. (11 L) 16.8 qt. (16 L) 51.6 qt (49 L) 52.8 qt. (50 L) 52.8 qt. (50 L) 54.8 qt. (52 L) 54.8 qt. (52 L)	Coolant w/cab Coolant w/open station Crankcase Hydraulic (PowrQuad 16/16) Hydraulic (PowrQuad 24/24) Hydraulic (AutoQuad 24/24) Hydraulic (SyncroPlus 12/4) Hydraulic (PowrReverser 16/16)
Tractor	6130D	17.4 qt. (16.5 L) 13 qt. (12 L) 61.2 qt. (58 L)	Coolant Crankcase Hydraulic/transmission

Machine	Model	Capacities	Description
Tractor	6140D	17.4 qt. (16.5 L) 13 qt. (12 L) 61.2 qt. (58 L)	Coolant Crankcase Hydraulic/transmission
Tractor	6200	14.3 qt. (13.5 L) 11.6 qt. (11 L) 12.7 qt. (12 L) 54.8 qt. (52 L) 51.6 qt. (49 L) 54.8 qt. (52 L) 1.2 qt. (1 L) 3.2 qt. (3 L)	Coolant w/cab Coolant w/o cab Crankcase Hydraulic (SyncroPlus) Transmission (PowerQuad) Transmission (SyncroPlus) Extra for Creeper Extra for FWD
Tractor	6210	14.3 qt. (13.5 L) 11.6 qt. (11 L) 12.7 qt. (12 L) 51.6 qt. (49 L) 54.8 qt. (52 L) 1.2 qt. (1 L) 3.2 qt. (3 L) 3.2 qt. (3 L)	Coolant w/cab Coolant w/o cab Crankcase Transmission (PowerQuad) Transmission (SyncroPlus) Extra for Creeper Extra for FWD Extra for TLS
Tractor	6215	11.6 qt. (11L) 14.3 qt. (13.5 L) 16.8 qt. (16L) 54.8 qt. (52 L) 1.2 qt. (1 L) 3.2 qt. (3 L)	Coolant (Open station) Coolant (cab) Crankcase Hydraulic Extra for Creeper Extra for FWD
Tractor	6220	14.3 qt. (13.5 L) 11.6 qt. (11 L) 16 qt. (15.1 L) 51.6 qt (49 L) 52.8 qt. (50 L) 52.8 qt. (50 L) 54.8 qt. (52 L)	Coolant w/cab Coolant w/open station Crankcase Hydraulic (PowrQuad 16/16) Hydraulic (PowrQuad 24/24) Hydraulic (AutoQuad 24/24) Hydraulic (SyncroPlus 12/4)

Machine	Model	Capacities	Description
Tractor	6230	54.8 qt. (52 L)	Hydraulic (PowrReverser 16/16)
		29 L (7.7 gal)	Coolant w/cab
		26.5 L (7 gal)	Coolant w/o cab
		16 L (4.2 gal)	Crankcase
		50 L (13.2 gal)	PowerQuad Plus trans 16/16 gears
		50 L (13.2 gal)	PowerQuad Plus trans 24/24 gears
		50 L (13.2 gal)	AutoQuad Plus trans 24/24 gears
		49 L (12.9 gal)	PowerQuad trans 16/16 gears
		50 L (13.2 gal)	PowerQuad trans 24/24 gears
		54.8 qt. (52 L)	PowrReverser trans 16/16
		54.8 qt. (52 L)	SyncroPlus trans 12/4
		1 L (0.3 gal)	Extra with creeper trans
3 L (0.8 gal)	Extra with front-wheel drive		
Tractor	6230PR	29 L (7.7 gal)	Coolant
		16 L (4.2 gal)	Crankcase
		49 L (12.9 gal)	PowerQuad Plus trans 16/16 gears
		50 L (13.2 gal)	PowerQuad Plus trans 24/24 gears
		50 L (13.2 gal)	AutoQuad Plus trans 24/24 gears
		60 L (15.9 gal)	IVT trans
		1 L (0.3 gal)	Extra with creeper trans
		3 L (0.8 gal)	Extra with front-wheel drive
		3 L (0.8 gal)	Extra with TLS axle
Tractor	6300	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase
		51.6 qt. (49 L)	Transmission (PowerQuad)
		54.8 qt. (52 L)	Transmission (SyncroPlus)
		1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD
Tractor	6310	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase

Machine	Model	Capacities	Description
		51.6 qt. (49 L) 54.8 qt. (52 L)	Transmission (PowerQuad) Transmission (SyncroPlus)
Tractor	6320	14.3 qt. (13.5 L) 11.6 qt. (11 L) 16 qt. (15.1 L) 51.6 qt (49 L) 52.8 qt. (50 L) 52.8 qt. (50 L) 54.8 qt. (52 L) 54.8 qt. (52 L)	Coolant w/cab Coolant w/open station Crankcase Hydraulic (PowrQuad 16/16) Hydraulic (PowrQuad 24/24) Hydraulic (AutoQuad 24/24) Hydraulic (SyncroPlus 12/4) Hydraulic (PowrReverser 16/16)
Tractor	6330	29 L (7.7 gal) 26.5 L (7 gal) 16 L (4.2 gal) 50 L (13.2 gal) 50 L (13.2 gal) 50 L (13.2 gal) 49 L (12.9 gal) 50 L (13.2 gal) 54.8 qt. (52 L) 54.8 qt. (52 L) 1 L (0.3 gal) 3 L (0.8 gal)	Coolant w/cab Coolant w/o cab Crankcase PowerQuad Plus trans 16/16 gears PowerQuad Plus trans 24/24 gears AutoQuad Plus trans 24/24 gears PowerQuad trans 16/16 gears PowerQuad trans 24/24 gears PowrReverser trans 16/16 SyncroPlus trans 12/4 Extra with creeper trans Extra with front-wheel drive
Tractor	6330PR	29 L (7.7 gal) 16 L (4.2 gal) 49 L (12.9gal) 50 L (13.2 gal) 50 L (13.2 gal) 60 L (15.9 gal) 1 L (0.3 gal) 3 L (0.8 gal) 3 L (0.8 gal)	Coolant Crankcase PowerQuad Plus trans 16/16 gears PowerQuad Plus trans 24/24 gears AutoQuad Plus trans 24/24 gears IVT trans Extra with creeper trans Extra with front-wheel drive Extra with TLS axle

Machine	Model	Capacities	Description
Tractor	6400	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase
		51.6 qt. (49 L)	Transmission (PowerQuad)
		54.8 qt. (52 L)	Transmission (SyncroPlus)
		1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD
Tractor	6403	14.3 qt. (13.5 L)	Cooling
		13 qt. (12 L)	Crankcase
		61.2 qt.(58 L)	Hydraulic
		5.3 qt. (5 L)	Extra for MFWD
Tractor	6405	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase
		54.8 qt. (52 L)	Hydraulic
Tractor	6410	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase
		51.6 qt. (49 L)	Transmission (PowerQuad)
		54.8 qt. (52 L)	Transmission (SyncroPlus)
		1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD
		3.2 qt. (3 L)	Extra for TLS
Tractor	6415	11.6 qt. (11L)	Coolant (open station)
		14.3 qt. (13.5 L)	Coolant (cab)
		16.8 qt. (15.9L)	Crankcase
		54.8 qt. (52 L)	Hydraulic
		1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD

Machine	Model	Capacities	Description
Tractor	6420	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/open station
		16 qt. (15.1 L)	Crankcase
		51.6 qt (49 L)	Hydraulic (PowrQuad 16/16)
		52.8 qt. (50 L)	Hydraulic (PowrQuad 24/24)
		52.8 qt. (50 L)	Hydraulic (AutoQuad 24/24)
		54.8 qt. (52 L)	Hydraulic (SyncroPlus 12/4)
		54.8 qt. (52 L)	Hydraulic (PowrReverser 16/16)
Tractor	6420	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/open station
		16 qt. (15.1 L)	Crankcase
		51.6 qt (49 L)	Hydraulic (PowrQuad 16/16)
		52.8 qt. (50 L)	Hydraulic (PowrQuad 24/24)
		52.8 qt. (50 L)	Hydraulic (AutoQuad 24/24)
		54.8 qt. (52 L)	Hydraulic (SyncroPlus 12/4)
		54.8 qt. (52 L)	Hydraulic (PowrReverser 16/16)
Tractor	6430	29 L (7.7 gal)	Coolant w/cab
		26.5 L (7 gal)	Coolant w/o cab
		16 L (4.2 gal)	Crankcase
		50 L (13.2 gal)	PowerQuad Plus trans 16/16 gears
		50 L (13.2 gal)	PowerQuad Plus trans 24/24 gears
		50 L (13.2 gal)	AutoQuad Plus trans 24/24 gears
		49 L (12.9 gal)	PowerQuad trans 16/16 gears
		50 L (13.2 gal)	PowerQuad trans 24/24 gears
		54.8 qt. (52 L)	PowrReverser trans 16/16
		54.8 qt. (52 L)	SyncroPlus trans 12/4
		1 L (0.3 gal)	Extra with creeper trans
		3 L (0.8 gal)	Extra with front-wheel drive
Tractor	6430PR	29 L (7.7 gal)	Coolant
		16 L (4.2 gal)	Crankcase

Machine	Model	Capacities	Description
		49 L (12.9gal)	PowerQuad Plus trans 16/16 gears
		50 L (13.2 gal)	PowerQuad Plus trans 24/24 gears
		50 L (13.2 gal)	AutoQuad Plus trans 24/24 gears
		60 L (15.9 gal)	IVT trans
		1 L (0.3 gal)	extra with creeper trans
		3 L (0.8 gal)	extra with front-wheel drive
		3 L (0.8 gal)	extra with TLS axle
Tractor	6500	14.3 qt. (13.5 L)	Coolant w/cab
		11.6 qt. (11 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase
		51.6 qt. (49 L)	Transmission (PowerQuad)
		54.8 qt. (52 L)	Transmission (SyncroPlus)
		1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD
Tractor	6603	19.5 qt. (18.5 L)	Cooling
		20 qt. (19 L)	Crankcase
		61.2 qt.(58 L)	Hydraulic
		5.3 qt. (5 L)	Extra for MFWD
Tractor	6605	16.4 qt. (15.5 L)	Coolant w/cab
		13.7 qt. (13 L)	Coolant w/o cab
		12.7 qt. (12 L)	Crankcase
		54.8 qt. (52 L)	Hydraulic
Tractor	6615	16.4 qt. (15.5 L)	Coolant
		22 qt (20L)	Crankcase
		54.8 qt. (52 L)	Hydraulic
		1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD
Tractor	6715	16.4 qt. (15.5 L)	Coolant
		22 qt (20L)	Crankcase
		54.8 qt. (52 L)	Hydraulic

Machine	Model	Capacities	Description
Tractor	7020	1.2 qt. (1 L)	Extra for Creeper
		3.2 qt. (3 L)	Extra for FWD
		32 qt. (30 L)	Coolant (4WD)
		17 qt. (16 L)	Crankcase (4WD)
		20 qt. (18.9 L)	Front differential (4WD)
Tractor	7130	88 qt. (83 L)	Hydraulic/transmission (4WD)
		8.9 gal (33.6 L)	Coolant with cab
		8.2 gal (31.1 L)	Coolant w/o cab
		5.2 gal (19.5 L)	Engine Crankcase
		13.7 gal. (52 L)	PowerQuad Plus Tran
		13.7 gal. (52 L)	AutoQuad Plus Tran
		13.7 gal. (52 L)	PowrReverser Tran
		13.7 gal. (52 L)	SyncroPlus Trans
		0.3 gal. (1 L)	- extra creeper
0.8 gal. (3 L)	- extra with front-wheel drive		
Tractor	7130PR	8.9 gal (33.6 L)	Coolant
		5.2 gal (19.5 L)	Engine Crankcase
		13.7 gal. (52 L)	PowerQuad Plus Tran
		13.7 gal. (52 L)	AutoQuad Plus Tran
		15.9 gal. (60 L)	IVT Trans
		0.3 gal. (1 L)	- extra creeper
		0.8 gal. (3 L)	- extra with front-wheel drive
		0.8 gal. (3 L)	- extra with TLS
Tractor	7200	20 qt. (19 L)	Coolant
		19 qt. (18 L)	Crankcase
		60 qt. (57 L)	Hydraulic/transmission (PowrQuad)
		64 qt. (61 L)	Hydraulic/transmission (PowrQuad) (w/creeper)
		64 qt. (68 L)	Hydraulic/transmission (PowrQuad) (w/MFWD and creeper)
		68 qt. (64 L)	Hydraulic/transmission (PowrQuad) (w/MFWD)
		60 qt. (57 L)	Hydraulic/transmission (SyncroPlus)

Machine	Model	Capacities	Description
Tractor	7210	68 qt. (64 L)	Hydraulic/transmission (SyncroPlus) (w/MFWD)
		64 qt. (61 L)	Hydraulic/transmission (w/creeper)
		72 qt. (68 L)	Hydraulic/transmission (w/MFWD and creeper)
		20 qt. (19 L)	Coolant
		20 qt. (19 L)	Crankcase
		60 qt. (57 L)	Hydraulic/transmission (PowrQuad)
		64 qt. (61 L)	Hydraulic/transmission (PowrQuad) (w/creeper)
		64 qt. (68 L)	Hydraulic/transmission (PowrQuad) (w/MFWD and creeper)
		68 qt. (64 L)	Hydraulic/transmission (PowrQuad) (w/MFWD)
		60 qt. (57 L)	Hydraulic/transmission (SyncroPlus)
68 qt. (64 L)	Hydraulic/transmission (SyncroPlus) (w/MFWD)		
64 qt. (61 L)	Hydraulic/transmission (w/creeper)		
72 qt. (68 L)	Hydraulic/transmission (w/MFWD and creeper)		
Tractor	7220	17 qt. (15.5 L)	Coolant
		22.2 qt. (21 L)	Crankcase
		54.8 qt. (52 L)	Hydraulic/transmission (PQ)
		8.4 qt. (8 L)	MFWD with TLS
		6.8 qt. (6.6 L)	MFWD w/o TLS
Tractor	7230	8.9 gal (33.6 L)	Coolant with cab
		8.2 gal (31.1 L)	Coolant w/o cab
		5.2 gal (19.5 L)	Engine Crankcase
		13.7 gal. (52 L)	PowerQuad Plus Tran
		13.7 gal. (52 L)	AutoQuad Plus Tran
		13.7 gal. (52 L)	PowrReverser Tran
		13.7 gal. (52 L)	SyncroPlus Trans
		0.3 gal. (1 L)	- extra creeper
		0.8 gal. (3 L)	- extra with front-wheel drive

Machine	Model	Capacities	Description
Tractor	7230PR	8.9 gal (33.6 L) 5.2 gal (19.5 L) 13.7 gal. (52 L) 13.7 gal. (52 L) 15.9 gal. (60 L) 0.3 gal. (1 L) 0.8 gal. (3 L) 0.8 gal. (3 L)	Coolant Engine Crankcase PowerQuad Plus Tran AutoQuad Plus Tran IVT Trans - extra creeper - extra with front-wheel drive - extra with TLS
Tractor	7320	25.2 qt. (24 L) 22.2 qt. (21 L) 63.6 qt. (60 L) 54.8 qt. (52 L) 8.4 qt. (8 L) 6.8 qt. (6.6 L)	Coolant Crankcase Hydraulic/transmission (IVT) Hydraulic/transmission (PQ) MFWD with TLS MFWD w/o TLS
Tractor	7330PR	8.9 gal (33.6 L) 5.2 gal (19.5 L) 14.8 gal. (56 L) 14.8 gal. (56 L) 17.4 gal. (66 L) 0.3 gal. (1 L) 0.8 gal. (3 L) 0.8 gal. (3 L)	Coolant Engine Crankcase PowerQuad Plus Tran AutoQuad Plus Tran IVT Trans - extra creeper - extra with front-wheel drive - extra with TLS
Tractor	7330	8.9 gal (33.6 L) 8.2 gal (31.1 L) 5.2 gal (19.5 L) 13.7 gal. (52 L) 13.7 gal. (52 L) 13.7 gal. (52 L) 13.7 gal. (52 L) 0.3 gal. (1 L) 0.8 gal. (3 L)	Coolant with cab Coolant w/o cab Engine Crankcase PowerQuad Plus Tran AutoQuad Plus Tran PowrReverser Tran SyncroPlus Trans - extra creeper - extra with front-wheel drive
Tractor	7400	20 qt. (19 L)	Coolant

Machine**Model****Capacities****Description**[Back to top](#)

		19 qt. (18 L)	Crankcase
		60 qt. (57 L)	Hydraulic/transmission (PowrQuad)
		64 qt. (61 L)	Hydraulic/transmission (PowrQuad) (w/creeper)
		64 qt. (68 L)	Hydraulic/transmission (PowrQuad) (w/MFWD and creeper)
		68 qt. (64 L)	Hydraulic/transmission (PowrQuad) (w/MFWD)
		60 qt. (57 L)	Hydraulic/transmission (SynchroPlus)
		68 qt. (64 L)	Hydraulic/transmission (SynchroPlus) (w/MFWD)
		64 qt. (61 L)	Hydraulic/transmission (w/creeper)
		72 qt. (68 L)	Hydraulic/transmission (w/MFWD and creeper)
Tractor	7405	20 qt. (19 L)	Coolant
		19 qt. (18 L)	Crankcase
		60 qt. (57 L)	Hydraulic/transmission (PowrQuad)
		64 qt. (68 L)	Hydraulic/transmission (PowrQuad) (w/MFWD and creeper)
		68 qt. (64 L)	Hydraulic/transmission (PowrQuad) (w/MFWD)
Tractor	7410	20 qt. (19 L)	Coolant
		20 qt. (19 L)	Crankcase
		60 qt. (57 L)	Hydraulic/transmission (PowrQuad)
		64 qt. (61 L)	Hydraulic/transmission (PowrQuad) (w/creeper)
		64 qt. (68 L)	Hydraulic/transmission (PowrQuad) (w/MFWD and creeper)
		68 qt. (64 L)	Hydraulic/transmission (PowrQuad) (w/MFWD)
		60 qt. (57 L)	Hydraulic/transmission (SynchroPlus)
		68 qt. (64 L)	Hydraulic/transmission (SynchroPlus) (w/MFWD)
		64 qt. (61 L)	Hydraulic/transmission (w/creeper)
		72 qt. (68 L)	Hydraulic/transmission (w/MFWD and creeper)

Machine	Model	Capacities	Description
Tractor	7420	29.6 qt. (28 L) 22.2 qt. (21 L) 69.6 qt. (66 L) 59.2 qt. (56 L) 0.3 gal. (1 L) 0.8 gal. (3 L) 0.8 gal. (3 L)	Coolant Crankcase Hydraulic/transmission (IVT) Hydraulic/transmission (PQ) - extra creeper - extra with front-wheel drive - extra with TLS
Tractor	7430PR	9.4 gal (35.6 L) 5.2 gal (19.5 L) 14.8 gal. (56 L) 14.8 gal. (56 L) 17.4 gal. (66 L) 0.3 gal. (1 L) 0.8 gal. (3 L) 0.8 gal. (3 L)	Coolant Engine Crankcase PowerQuad Plus Tran AutoQuad Plus Tran IVT Trans - extra creeper - extra with front-wheel drive - extra with TLS
Tractor	7510	20 qt. (19 L) 20 qt. (19 L) 60 qt. (57 L) 64 qt. (61 L) 64 qt. (68 L) 68 qt. (64 L) 60 qt. (57 L) 68 qt. (64 L) 64 qt. (61 L) 72 qt. (68 L)	Coolant Crankcase Hydraulic/transmission (PowrQuad) Hydraulic/transmission (PowrQuad) (w/creeper) Hydraulic/transmission (PowrQuad) (w/MFWD and creeper) Hydraulic/transmission (PowrQuad) (w/MFWD) Hydraulic/transmission (SyncroPlus) Hydraulic/transmission (SyncroPlus) (w/MFWD) Hydraulic/transmission (w/creeper) Hydraulic/transmission (w/MFWD and creeper)
Tractor	7520	29.6 qt. (28 L) 22.2 qt. (21 L) 69.6 qt. (66 L) 59.2 qt. (56 L)	Coolant Crankcase Hydraulic/transmission (IVT) Hydraulic/transmission (PQ)

Machine**Model****Capacities****Description**[Back to top](#)

		0.3 gal. (1 L) 0.8 gal. (3 L) 0.8 gal. (3 L)	- extra creeper - extra with front-wheel drive - extra with TLS
Tractor	7520 (1975)	40 qt. (38 L) 26 qt. (24.6 L) 28 qt. (26 L) 76 qt. (72 L)	Coolant (4WD) Crankcase (4WD) Front differential (4WD) Hydraulic/transmission (4WD)
Tractor	7530PR	9.4 gal (35.6 L) 5.2 gal (19.5 L) 14.8 gal. (56 L) 14.8 gal. (56 L) 17.4 gal. (66 L) 0.3 gal. (1 L) 0.8 gal. (3 L) 0.8 gal. (3 L)	Coolant Engine Crankcase PowerQuad Plus Tran AutoQuad Plus Tran IVT Trans - extra creeper - extra with front-wheel drive - extra with TLS
Tractor	7600	25 qt. (24 L) 19 qt. (18 L) 108 qt. (102.3 L) 108 qt. (102.3 L) 63.6 qt. (98.3 L)	Coolant Crankcase Hydraulic/transmission (Powershift) Hydraulic/transmission (PowrQuad w/creeper) Hydraulic/transmission (PowrQuad)
Tractor	7610	20 qt. (19 L) 20 qt. (19 L) 108 qt. (102.3 L) 96 qt. (91 L) 108 qt. (102.3 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L)	Coolant Crankcase Hydraulic/transmission (Powershift w/MFWD) Hydraulic/transmission (Powershift) Hydraulic/transmission (PowrQuad w/MFWD and creeper) Hydraulic/transmission (PowrQuad w/MFWD) Hydraulic/transmission (PowrQuad)
Tractor	7630	29.3 L (31.1 qt) 26 L (27.5 qt) 108 L (28.5 gal)	Coolant Crankcase Hydraulic/Transmission
Tractor	7700	27.5 qt. (26 L) 19 qt. (18 L)	Coolant Crankcase

Machine**Model****Capacities****Description**[Back to top](#)

		108 qt. (102.3 L) 103.6 qt. (98.3 L) 108 qt. (102.3 L)	Hydraulic/transmission (Powershift) Hydraulic/transmission (PowrQuad) Hydraulic/transmission (PowrQuad with creeper),
Tractor	7710	20 qt. (19 L) 25 qt. (24 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 108 qt. (102.3 L) 96 qt. (91 L) 108 qt. (102.3 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 27.5 U.S. qt. (26 L) 26.4 U.S. qt. (25 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 108 qt. (102.3 L) 96 qt. (91 L) 108 qt. (102.3 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 108 qt. (102.3 L)	Coolant(-89999) Crankcase(-89999) Hydraulic/transmission (AutoQuad II w/MFWD)(-89999) Hydraulic/transmission (AutoQuad II)(-89999) Hydraulic/transmission (Powershift w/MFWD)(-89999) Hydraulic/transmission (Powershift)(-89999) Hydraulic/transmission (PowrQuad w/MFWD and creeper)(-89999) Hydraulic/transmission (PowrQuad w/MFWD)(-89999) Hydraulic/transmission (PowrQuad)(-89999) Coolant(90000-) Crankcase(90000-) Hydraulic/transmission (AutoQuad II w/MFWD)(90000-) Hydraulic/transmission (AutoQuad II)(90000-) Hydraulic/transmission (Powershift w/MFWD)(90000-) Hydraulic/transmission (Powershift)(90000-) Hydraulic/transmission (PowrQuad w/MFWD and creeper)(90000-) Hydraulic/transmission (PowrQuad w/MFWD)(90000-) Hydraulic/transmission (PowrQuad)(90000-) Hydraulic/transmission (IVT) (90000-)
Tractor	7720	33.8 qt. (32L) 27.5 qt. (26L) 114 qt. (108L)	Coolant Crankcase Hydraulic/Transmission

Machine	Model	Capacities	Description
Tractor	7730	29.3 L (31.1 qt) 26 L (27.5 qt) 108 L (28.5 gal)	Coolant Crankcase Hydraulic/Transmission
Tractor	7800	27.5 qt. (26 L) 19 qt. (18 L) 108 qt. (102.3 L) 103.6 qt. (98.3 L)	Coolant(-89999) Crankcase(-89999) Hydraulic/transmission (Powershift)(-89999) Hydraulic/transmission (PowrQuad)(-89999)
Tractor	7810	20 qt. (19 L) 25 qt. (24 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 108 qt. (102.3 L) 96 qt. (91 L) 108 qt. (102.3 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 27.5 U.S. qt. (26 L) 26.4 U.S. qt. (25 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 108 qt. (102.3 L) 96 qt. (91 L) 108 qt. (102.3 L) 103.6 qt. (98.3 L) 91.6 qt. (87 L) 108 qt. (102.3 L)	Coolant(-89999) Crankcase(-89999) Hydraulic/transmission (AutoQuad II w/MFWD)(-89999) Hydraulic/transmission (AutoQuad II)(-89999) Hydraulic/transmission (Powershift w/MFWD)(-89999) Hydraulic/transmission (Powershift)(-89999) Hydraulic/transmission (PowrQuad w/MFWD and creeper)(-89999) Hydraulic/transmission (PowrQuad w/MFWD)(-89999) Hydraulic/transmission (PowrQuad)(-89999) Coolant(90000-) Crankcase(90000-) Hydraulic/transmission (AutoQuad II w/MFWD)(90000-) Hydraulic/transmission (AutoQuad II)(90000-) Hydraulic/transmission (Powershift w/MFWD)(90000-) Hydraulic/transmission (Powershift)(90000-) Hydraulic/transmission (PowrQuad w/MFWD and creeper)(90000-) Hydraulic/transmission (PowrQuad w/MFWD)(90000-) Hydraulic/transmission (PowrQuad)(90000-) Hydraulic/transmission (IVT) (90000-)

Machine	Model	Capacities	Description
Tractor	7820	33.8 qt. (32L) 25.4 qt. (24L) 114 qt. (108L)	Coolant Crankcase Hydraulic/Transmission
Tractor	7830	29.3 L (31.1 qt) 26 L (27.5 qt) 108 L (28.5 gal)	Coolant Crankcase Hydraulic/Transmission
Tractor	7920	33.8 qt. (32L) 25.4 qt. (24L) 114 qt. (108L)	Coolant Crankcase Hydraulic/Transmission
Tractor	7930	29.3 L (31.1 qt) 26 L (27.5 qt) 108 L (28.5 gal)	Coolant Crankcase Hydraulic/Transmission
Tractor	8100	35.9 qt. (34 L) 22.7 qt. (21.5 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic
Tractor	8100T	35.9 qt. (34 L) 22.7 qt. (21.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8110	35.9 qt. (34 L) 22.7 qt. (21.5 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic -- includes 24 qt. (22.7 L) for clean oil reservoir
Tractor	8110T	35.9 qt. (34 L) 22.7 qt. (21.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8120	35.9 qt. (34 L)	Coolant

Machine	Model	Capacities	Description
		22.7 qt. (21.5 L) 148 qt. (140 L) 158.4 qt. (150 L)	Crankcase Hydraulic MFWD Hydraulic MFWD with ILS
Tractor	8120T	35.9 qt. (34 L) 22.7 qt. (21.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8130	42.3 qt. (42L) 25.5 qt (24L) 25.5 qt (24L) 26.0 qt. (24.5L) 43.0 gal (165 L) 46.0 gal (175 L) 14.2 qt. (13.6) 3.6 qt. (3.4 L) 4.2 qt. (4.0L)	Coolant Crankcase (2WD) Crankcase (MFWD) Crankcase (ILS) Hydraulic (MFWD) Hydraulic (ILS) MFWD Housing MFWD hub each ILS hub each
Tractor	8200	35.9 qt. (34 L) 26.4 qt. (25 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic
Tractor	8200T	35.9 qt. (34 L) 24.8 qt. (23.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8210	35.9 qt. (34 L) 26.4 qt. (25 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic -- includes 24 qt. (22.7 L) for clean oil reservoir
Tractor	8210T	35.9 qt. (34 L) 24.8 qt. (23.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir

Machine	Model	Capacities	Description
Tractor	8220	35.9 qt. (34 L) 24.8 qt. (23.5 L) 148 qt. (140 L) 158.4 qt. (150 L)	Coolant Crankcase Hydraulic MFWD Hydraulic MFWD with ILS
Tractor	8220T	35.9 qt. (34 L) 24.8 qt. (23.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8225R	42.3 qt. (40 L) 26.4 qt. (25 L)	Coolant Crankcase
Tractor	8230	42.3 qt. (42L) 25.5 qt (24L) 26.0 qt. (24.5L) 43.0 gal (165L) 46.0 gal (175L) 14.2 qt. (13.6L) 19.7 qt. (18.7L) 3.6 qt. (3.4 L) 4.2 qt. (4.0L)	Coolant Crankcase (2WD or 1300 MFWD) Crankcase (ILS or 1500 MFWD) Hydraulic (2WD or MFWD) Hydraulic (ILS) 1300 MFWD Housing 1500 MFWD Housing MFWD hub each ILS hub each
Tractor	8230T	42.3 qt (40L) 25.5 qt (24L) 65 gal (246L)	Coolant Crankcase Transmission, hydraulic
Tractor	8245R	42.3 qt. (40 L) 26.4 qt. (25 L)	Coolant Crankcase
Tractor	8270R	42.3 qt. (40 L) 26.4 qt. (25 L)	Coolant Crankcase
Tractor	8295R	42.3 qt. (40 L) 26.4 qt. (25 L) 29.5 qt. (28 L)	Coolant Crankcase (2WD or 1300 MFWD) Crankcase (ILS or 1500 MFWD)

Machine	Model	Capacities	Description
		26.4 qt. (25 L) 260 qt. (246 L)	Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8310	35.9 qt. (34 L) 26.4 qt. (25 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic -- includes 24 qt. (22.7 L) for clean oil reservoir
Tractor	8310T	35.9 qt. (34 L) 26.4 qt. (25 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8320	35.9 qt. (34 L) 26.4 qt. (25 L) 148 qt. (140 L) 158.4 qt. (150 L)	Coolant Crankcase Hydraulic MFWD Hydraulic MFWD with ILS
Tractor	8320T	35.9 qt. (34 L) 26.4 qt. (25 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8320R	42.3 qt. (40 L) 26.4 qt. (25 L) 29.5 qt. (28 L)	Coolant Crankcase (2WD or 1300 MFWD) Crankcase (ILS or 1500 MFWD)
Tractor	8320RT	42.3 qt. (40 L) 27 qt. (25.5 L) 273.2 qt. (258 L)	Coolant Crankcase Transmission/Hydraulic
Tractor	8330	42.3 qt. (42L) 25.5 qt (24L) 26.0 qt. (24.5L) 43.0 gal (165L) 46.0 gal (175L)	Coolant Crankcase (2WD or 1300 MFWD) Crankcase (ILS or 1500 MFWD) Hydraulic (2WD or MFWD) Hydraulic (ILS)

Machine	Model	Capacities	Description
Tractor	8295R	42.3 qt. (40 L) 27 qt. (25.5 L) 273.2 qt. (258 L)	Coolant Crankcase Transmission/Hydraulic
Tractor	8300	35.9 qt. (34 L) 26.4 qt. (25 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic
Tractor	8300T	35.9 qt. (34 L) 14.2 qt. (13.6L) 19.7 qt. (18.7L) 3.6 qt. (3.4 L) 4.2 qt. (4.0L)	Coolant 1300 MFWD Housing 1500 MFWD Housing MFWD hub each ILS hub each
Tractor	8330T	42.3 qt (40L) 27.0 qt (25.5L) 65 gal. (246L)	Coolant Crankcase Transmission, hydraulic
Tractor	8345R	42.3 qt. (40 L) 26.4 qt. (25 L) 29.5 qt. (28 L)	Coolant Crankcase (2WD or 1300 MFWD) Crankcase (ILS or 1500 MFWD)
Tractor	8345RT	42.3 qt. (40 L) 27 qt. (25.5 L) 273.2 qt. (258 L)	Coolant Crankcase Transmission/Hydraulic
Tractor	8400	35.9 qt. (34 L) 28.5 qt. (27 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic
Tractor	8400T	35.9 qt. (34 L) 28.5 qt. (27 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir

Machine	Model	Capacities	Description
Tractor	8410	35.9 qt. (34 L) 28.5 qt. (27 L) 148 qt. (140 L)	Coolant Crankcase Transmission/hydraulic -- includes 24 qt. (22.7 L) for clean oil reservoir
Tractor	8410T	35.9 qt. (34 L) 28.5 qt. (27 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8420	35.9 qt. (34 L) 28.5 qt. (27 L) 148 qt. (140 L) 158.4 qt. (150 L)	Coolant Crankcase Hydraulic MFWD Hydraulic MFWD with ILS
Tractor	8420T	35.9 qt. (34 L) 28.5 qt. (27 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8430	42.3 qt. (42L) 27 qt (25.5L) 26.0 qt. (24.5L) 43.0 gal (165L) 46.0 gal (175L) 14.2 qt. (13.6L) 19.7 qt. (18.7L) 3.6 qt. (3.4 L) 4.2 qt. (4.0L)	Coolant Crankcase (2WD or 1300 MFWD) Crankcase (ILS or 1500 MFWD) Hydraulic (2WD or MFWD) Hydraulic (ILS) 1300 MFWD Housing 1500 MFWD Housing MFWD hub each ILS hub each
Tractor	8430 (1978)	40 qt. (38 L) 22 qt. (21 L) 27 qt. (26 L) 104 qt. (98 L) 112 qt. (106 L)	Coolant (4WD) Crankcase (4WD) Front differential (4WD) Hydraulic (4WD) Transmission (4WD)

Machine	Model	Capacities	Description
Tractor	8430T	42.3 qt (40L) 27.0 qt (25.5L) 65 gal. (246L)	Coolant Crankcase Transmission, hydraulic
Tractor	8440	42 qt. (40 L) 20 qt. (19 L) 140 qt. (132 L)	Coolant (4WD) Crankcase (4WD) Hydraulic/transmission (4WD)
Tractor	8450	42 qt. (40 L) 20 qt. (18.9 L) 150 qt. (142 L)	Coolant (4WD) Crankcase (4WD) Hydraulic (4WD)
Tractor	8520	35.9 qt. (34 L) 32.7 qt. (31.0 L) 148 qt. (140 L) 158.4 qt. (150 L)	Coolant Crankcase Hydraulic MFWD Hydraulic MFWD with ILS
Tractor	8520T	35.9 qt. (34 L) 33.3 qt. (31.5 L) 260 qt. (246 L)	Coolant Crankcase Transmission -- includes 44 qt.(41.64 L) for clean oil reservoir
Tractor	8530	42.3 qt. (42L) 29.5 qt. (28L) 43.0 gal (165L) 46.0 gal (175L) 19.7 qt. (18.7L) 3.6 qt. (3.4 L) 4.2 qt. (4.0L)	Coolant Crankcase (ILS or 1500 MFWD) Hydraulic (2WD or MFWD) Hydraulic (ILS) 1500 MFWD Housing MFWD hub each ILS hub each
Tractor	8560	58 qt. (55 L) 23 qt. (22 L) 152 qt. (144 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic (4WD) Reservoir (4WD) Transmission (4WD)

Machine	Model	Capacities	Description
Tractor	8570	58 qt. (55 L) 24.3 qt. (23 L) 152 qt. (144 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic (4WD) Reservoir (4WD) Transmission (4WD)
Tractor	8630 (1978)	44 qt. (42 L) 26 qt. (25 L) 28 qt. (26 L) 104 qt. (98 L)	Coolant (4WD) Crankcase (4WD) Front differential (4WD) Hydraulic/transmission (4WD)
Tractor	8640	51 qt. (48 L) 24 qt. (23 L) 28 qt. (26.5 L) 26 qt. (24.6 L) 144 qt. (136 L)	Coolant (4WD) Crankcase (-040123) (4WD) Crankcase (040124-) (4WD) Crankcase (w/o bypass) (066160-) (4WD) Hydraulic/transmission (4WD)
Tractor	8650	48 qt. (45.4 L) 28 qt. (26.5 L) 150 qt. (142 L)	Coolant (4WD) Crankcase (4WD) Hydraulic (4WD)
Tractor	8760	58 qt. (55 L) 36.5 qt. (34.5 L) 152 qt. (144 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic system (4WD) Reservoir (4WD) Transmission
Tractor	8770	58 qt. (55 L) 33.8 qt. (32 L) 152 qt. (144 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic system (4WD) Reservoir (4WD) Transmission
Tractor	8850	78 qt. (74 L) 51 qt. (48 L) 182 qt. (172 L)	Coolant (4WD) Crankcase (4WD) Hydraulic system (4WD)

Machine	Model	Capacities	Description
		150 qt. (141.9 L)	Reservoir (4WD)
Tractor	8870	58 qt. (55 L) 33.8 qt. (32 L) 152 qt. (144 L) 160 qt. (151 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic system (100mm axle) (4WD) Hydraulic system (110mm axle) (4WD) Reservoir (4WD) Transmission (4WD)
Tractor	8960	72 qt. (68.1 L) 39 qt. (37 L) 152 qt. (144 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic system (4WD) Reservoir (4WD) Transmission (4WD)
Tractor	8970	72 qt. (68.1 L) 39 qt. (37 L) 152 qt. (144 L) 56 qt. (53 L) 40 qt. (37.8 L)	Coolant (4WD) Crankcase (4WD) Hydraulic system (4WD) Reservoir (4WD) Transmission (4WD)
Tractor	9100	58 qt. (58 L) 104 qt. (102 L) 108 qt. (98 L) 80 qt. (76 L) 136 qt. (129 L) 140 qt. (131 L) 54 qt. (51 L) 56 qt. (53 L)	Coolant (4WD) Crankcase (4WD) Hydraulic w/hitch (4WD) Hydraulic w/o hitch (4WD) Transmission (12 speed/24 PowerSynch w/o PTO) (4WD) Transmission (12 speed/24 PowerSynch w/PTO) (4WD) Transmission (Powershift w/o PTO) (4WD) Transmission (Powershift w/PTO) (4WD)
Tractor	9120	55 qt. (52 L) 28 qt. (26.5 L) 27 gal.(103L) 34 gal.(129 L)	Coolant (4WD) Crankcase (4WD) Hydraulic w/o Hitch Transmission (24 PowerSync w/o PTO)

Machine	Model	Capacities	Description
		35 gal.(131L)	(4WD)
		35.5 gal.(134L)	Transmission (24 PowerSync w/PTO) (4WD)
		36.5 gal (138L)	Transmission (18 speed Powershift w/o PTO)
		1 gal. (3.8L)	Transmission (18 speed Powershift w/PTO) (4WD)
		3 gal. (10.5L)	Add for Hitch
			Add for High Flow Hitch
Tractor	9200	64 qt. (60 L)	Coolant (4WD)
		44 qt. (42 L)	Crankcase (4WD)
		108 qt. (102 L)	Hydraulic (w/hitch)
		104 qt. (98 L)	Hydraulic (w/o hitch)
		136 qt. (129 L)	Transmission (12 speed/24 PowerSynch) (w/o PTO) (4WD)
		140 qt. (131 L)	Transmission (12 speed/24 PowerSynch) w/PTO) (4WD)
		54 qt. (51 L)	Transmission (Powershift w/o PTO) (4WD)
		56 qt. (53 L)	Transmission (Powershift w/PTO) (4WD)
Tractor	9220	55 qt. (52 L)	Coolant (4WD)
		44 qt. (42 L)	Crankcase (4WD)
		27 gal.(103L)	Hydraulic w/o Hitch
		34 gal.(129 L)	Transmission (24 PowerSync w/o PTO) (4WD)
		35 gal.(131L)	Transmission (24 PowerSync w/PTO) (4WD)
		35.5 gal.(134L)	Transmission (18 speed Powershift w/o PTO) (4WD)
		36.5 gal (138L)	Transmission (18 speed Powershift w/PTO) (4WD)
		1 gal. (3.8L)	Add for Hitch
		3 gal. (10.5L)	Add for High Flow Hitch
Tractor	9230	12.5 gal (47.5L)	Coolant
		8.4 gal (31.8 L)	Crankcase
		37 gal. (140 L)	24-Speed Trans 100 mm axle (w/o PTO)
		38 gal. (144 L)	24-Speed Trans 100 mm axle (with PTO)
		38 gal. (144 L)	24-Speed Trans 110 mm axle (w/o PTO)
		39 gal. (148 L)	24-Speed Trans 110 mm axle (with PTO)

Machine	Model	Capacities	Description
		44 gal. (166.6 L)	PTS Trans 100 mm axle (w/o PTO)
		45 gal. (170.8 L)	PTS Trans 100 mm axle (with PTO)
		45 gal. (170 L)	PTS Trans 110 mm axle (w/o PTO)
		46 gal. (174.5 L)	PTS Trans 110 mm axle (with PTO)
		27 gal.(102 L)	Hydraulic system w/o Hitch-Standard
		28 gal.(106 L)	Hydraulic system with Hitch-Standard
		30 gal (113.5 L)	Hydraulic system w/o Hitch-High
		31 gal (117 L)	Hydraulic system with Hitch-High
Tractor	9300	64 qt. (60 L)	Coolant (4WD)
		44 qt. (42 L)	Crankcase (4WD)
		108 qt. (102 L)	Hydraulic w/hitch (4WD)
		104 qt. (98 L)	Hydraulic w/o hitch (4WD)
		136 qt. (129 L)	Transmission (12 speed/24 PowerSynch w/o PTO) (4WD)
		140 qt. (131 L)	Transmission (12 speed/24 PowerSynch w/PTO) (4WD)
		54 qt. (51 L)	Transmission (Powershift w/o PTO) (4WD)
		56 qt. (53 L)	Transmission (Powershift w/PTO) (4WD)
Tractor	9300T	64 qt. (60 L)	Coolant
		44 qt. (42 L)	Crankcase
		94 qt. (89 L)	Hydraulic w/hitch
		92 qt. (87 L)	Hydraulic w/o hitch
		68 qt. (64 L)	Transmission, 12 speed/24 PowerSynch w/o PTO
		72 qt. (68 L)	Transmission, 12 speed/24 PowerSynch w/PTO
Tractor	9320	64 qt. (60 L)	Coolant (4WD)
		44 qt. (42 L)	Crankcase (4WD)
		27 gal.(103L)	Hydraulic w/o Hitch
		34 gal.(129 L)	Transmission (24 PowerSync w/o PTO) (4WD)
		35 gal.(131L)	Transmission (24 PowerSync w/PTO) (4WD)
		35.5 gal.(134L)	Transmission (18 speed Powershift w/o PTO)

Machine	Model	Capacities	Description
		36.5 gal (138L)	(4WD) Transmission (18 speed Powershift w/PTO)
		1 gal. (3.8L)	(4WD) Add for Hitch
		3 gal. (10.5L)	Add for High Flow Hitch
Tractor	9320T	64 qt. (60 L)	Coolant
		44 qt. (42 L)	Crankcase
		27 gal. (103 L)	Hydraulic w/o hitch
		64 gal.(230 L)	Transmission (18 speed Powershift)
		65 gal.(246 L)	Transmission (24 PowerSynch)
		1 gal. (3.8L)	With hitch add
Tractor	9330	14 gal (53 L)	Coolant
		11 gal (42 L)	Crankcase
		37 gal. (140 L)	24-Speed Trans 100 mm axle (w/o PTO)
		38 gal. (144 L)	24-Speed Trans 100 mm axle (with PTO)
		38 gal. (144 L)	24-Speed Trans 110 mm axle (w/o PTO)
		39 gal. (148 L)	24-Speed Trans 110 mm axle (with PTO)
		45 gal. (170 L)	PTS Trans 110 mm axle (w/o PTO)
		46 gal. (174.5 L)	PTS Trans 110 mm axle (with PTO)
		27 gal. (102 L)	Hydraulic system w/o Hitch-Standard
		28 gal. (106 L)	Hydraulic system with Hitch-Standard
		30 gal (113.5 L)	Hydraulic system w/o Hitch-High
		31 gal (117 L)	Hydraulic system with Hitch-High
Tractor	9400	64 qt. (60 L)	Coolant (4WD)
		44 qt. (42 L)	Crankcase (4WD)
		108 qt. (102 L)	Hydraulic w/hitch (4WD)
		104 qt. (98 L)	Hydraulic w/o hitch (4WD)
		136 qt. (129 L)	Transmission (12 speed/24 PowerSynch w/o PTO) (4WD)
		140 qt. 131 L)	Transmission (12 speed/24 PowerSynch w/PTO) (4WD)
		54 qt. (51 L)	Transmission (Powershift w/o PTO) (4WD)
		56 qt. (53 L)	Transmission (Powershift w/PTO) (4WD)

Machine	Model	Capacities	Description
Tractor	9400T	64 qt. (60 L) 44 qt. (42 L) 94 qt. (89 L) 92 qt. (87 L) 72 qt. (68 L)	Coolant Crankcase Hydraulic w/hitch Hydraulic w/o hitch 68 qt. (64 L) Transmission (12 speed/24 PowerSynch) (w/o PTO) Transmission (12 speed/24 PowerSynch) (w/PTO)
Tractor	9420	64 qt. (60 L) 44 qt. (42 L) 27 gal.(103L) 34 gal.(129 L) 35 gal.(131L) 35.5 gal.(134L) 36.5 gal (138L) 1 gal. (3.8L) 3 gal. (10.5L)	Coolant (4WD) Crankcase (4WD) Hydraulic w/o Hitch Transmission (24 PowerSync w/o PTO) (4WD) Transmission (24 PowerSync w/PTO) (4WD) Transmission (18 speed Powershift w/o PTO) (4WD) Transmission (18 speed Powershift w/PTO) (4WD) Add for Hitch Add for High Flow Hitch
Tractor	9420T	64 qt. (60 L) 44 qt. (42 L) 27 gal. (103 L) 64 gal.(230 L) 65 gal.(246 L) 1 gal. (3.8L)	Coolant Crankcase Hydraulic w/o hitch Transmission (18 speed Powershift) Transmission (24 PowerSynch) With hitch add
Tractor	9430	14 gal (53 L) 11 gal (42 L) 38 gal. (144 L) 39 gal. (148 L) 45 gal. (170.8 L) 46 gal. (174.5 L) 27 gal.(102 L) 28 gal.(106 L)	Coolant Crankcase 24-Speed 110 mm axle (w/o PTO) 24-Speed 110 mm axle (with PTO) PST Transmission 110 mm axle (w/o PTO) PST Transmission 110 mm axle (with PTO) Hydraulic system w/o Hitch-Standard Hydraulic system with Hitch-Standard

Machine	Model	Capacities	Description
		30 gal (113.5 L) 31 gal (117 L)	Hydraulic system w/o Hitch-High Hydraulic system with Hitch-High
Tractor	9430T	14 gal. (53 L) 11 gal. (42 L) 27 gal. (102 L) 27.5 gal. (104 L) 47 gal. (178 L) 60 gal. (227 L) 61 gal. (230 L)	Coolant Crankcase Hydraulic w/o hitch Hydraulic with hitch Transmission (PTS) (Axle only) Transmission (PTS) (Trans w Axle) Transmission (PTS) (Trans w Axle) w PTO
Tractor	9520	64 qt. (60 L) 44 qt. (42 L) 27 gal.(103L) 35.5 gal.(134L) 36.5 gal (138L) 1 gal. (3.8L) 3 gal. (10.5L)	Coolant (4WD) Crankcase (4WD) Hydraulic w/o Hitch Transmission (18 speed Powershift w/o PTO) Transmission (18 speed Powershift w/PTO) Add for Hitch Add for High Flow Hitch
Tractor	9520T	64 qt. (60 L) 44 qt. (42 L) 27 gal.. (103 L) 64 gal.(230 L) 1 gal. (3.8L)	Coolant Crankcase Hydraulic w/o hitch Transmission (18 speed Powershift) With hitch add
Tractor	9530	14 gal (53 L) 15.8 gal (60 L) 23 gal. (87 L) 27 gal. (102 L) 28 gal. (106 L) 30 gal (113.5 L) 31 gal (117 L)	Coolant Crankcase PST trans 120 mm axle Hydraulic system w/o Hitch-Standard Hydraulic system with Hitch-Standard Hydraulic system w/o Hitch-High Hydraulic system with Hitch-High
Tractor	9530T	14 gal. (53 L) 15.8 gal. (60 L) 27 gal. (102 L)	Coolant Crankcase Hydraulic w/o hitch

Machine	Model	Capacities	Description
		27.5 gal. (104 L) 47 gal. (178 L) 60 gal. (227 L) 61 gal. (230 L)	Hydraulic with hitch Transmission (PTS) (Axle only) Transmission (PTS) (Trans w Axle) Transmission (PTS) (Trans w Axle) w PTO
Tractor	9620	64 qt. (60 L) 44 qt. (42 L) 27 gal.(103L) 35.5 gal.(134L) 36.5 gal (138L) 1 gal. (3.8L) 3 gal. (10.5L)	Coolant (4WD) Crankcase (4WD) Hydraulic w/o Hitch Transmission (18 speed Powershift w/o PTO) Transmission (18 speed Powershift w/PTO) Add for Hitch Add for High Flow Hitch
Tractor	9620T	64 qt. (60 L) 44 qt. (42 L) 27 gal.. (103 L) 64 gal.(230 L) 1 gal. (3.8L)	Coolant Crankcase Hydraulic w/o hitch Transmission (18 speed Powershift) With hitch add
Tractor	9630	14 gal (53 L) 15.8 gal (60 L) 23 gal. (87 L) 27 gal. (102 L) 28 gal. (106 L) 30 gal (113.5 L) 31 gal (117 L)	Coolant Crankcase PST Trans 120 mm axle Hydraulic system w/o Hitch-Standard Hydraulic system with Hitch-Standard Hydraulic system w/o Hitch-High Hydraulic system with Hitch-High
Tractor	9630T	14 gal. (53 L) 15.8 gal. (60 L) 27 gal. (102 L) 27.5 gal. (104 L) 47 gal. (178 L) 60 gal. (227 L) 61 gal. (230 L)	Coolant Crankcase Hydraulic w/o hitch Hydraulic with hitch Transmission (PTS) (Axle only) Transmission (PTS) (Trans w Axle) Transmission (PTS) (Trans w Axle) w PTO

Machine	Model	Capacities	Description
Windrowers			
Windrowers	A400	31 qt. (29.3 L) 12.6 qt. (12 L) 100 qt. (94.6 L)	Coolant Crankcase Hydraulic
Windrowers	R450	35 qt. (31.1 L) 12.6 qt. (12 L) 100 qt. (94.6 L)	Coolant Crankcase Hydraulic
Windrowers	800	12 qt. (11.4 L) 6 qt. (5.7 L) 3 qt. (2.8 L)	Coolant Crankcase Hydraulic/transmission
Windrowers	830	12 qt. (11.4 L) 6 qt. (5.7 L) 3 qt. (2.8 L)	Coolant Crankcase Hydraulic/transmission
Windrowers	880	14 qt. (13.2 L) 7 qt. (6.6 L) 32 qt. (30.2 L)	Coolant Crankcase Hydraulic/transmission
Windrowers	2250	14 qt. (13.2 L) 6 qt. (5.7 L) 9 qt. (8.5) 40 qt. (38 L) 2.5 qt. (2.4 L)	Coolant Crankcase Final drive Hydraulic/transmission Main drive
Windrowers	2270	14 qt. (13.2 L) 6 qt. (5.7 L) 9 qt. (8.5 L) 40 qt. (37.8 L) 2.5 qt. (2.4 L)	Coolant Crankcase Final drive Hydraulic/transmission Main drive
Windrowers	2280	14 qt. (13.2 L) 6 qt. (5.7 L)	Coolant Crankcase

Machine	Model	Capacities	Description
		9 qt. (8.5) 40 qt. (37.8 L) 2.5 qt. (2.4 L)	Final drive Hydraulic/transmission Main drive
Windrowers	2320	14 qt. (13.2 L) 6 qt. (5.7 L) 32 qt. (30.3 L)	Coolant Crankcase Hydraulic/transmission
Windrowers	2360	18 qt. (17 L) 7.9 qt. (7.5 L) 6 qt. (5.7 L) 50 qt. (47.3 L)	Coolant Crankcase (diesel) Crankcase (gas) Hydraulic/transmission
Windrowers	2420	14 qt. (13.2 L) 6 qt. (5.7 L) 32 qt. (30.3 L)	Coolant Crankcase Hydraulic/transmission
Windrowers	3430	14 qt. (13.2 L) 6 qt. (5.7 L) 38 qt. (36 L) 40 qt. (38 L)	Coolant Crankcase Hydraulic Transmission
Windrowers	3830	26 qt. (25 L) 9 qt. (8.5 L) 38 qt. (36 L) 40 qt. (38 L)	Coolant Crankcase Hydraulic Transmission
Windrowers	4890	29.6 qt. (27.8 L) 13 qt. (12.3 L) 100 qt. (94 L)	Coolant Crankcase Hydraulic
Windrowers	4895	29.6 qt. (27.8 L) 14 qt. (13.3 L) 100 qt. (94 L)	Coolant Crankcase Hydraulic

Machine	Model	Capacities	Description	Back to top
Windrowers	4990	34 qt. (32.4 L) 21 qt. (20 L) 100 qt. (94 L)	Coolant Crankcase Hydraulic	
Windrowers	4995	34.3 qt. (32.4L) 21 qt (20L) 100 qt. (94 L)	Coolant Crankcase Hydraulic	